


HCD-C70/C90

SERVICE MANUAL



HCD-C70 is the tuner CD player section in FH-C7X and MHC-C70. HCD-C90 is the tuner CD player section in MHC-C90.

Photo : HCD-C70 (AEP model)

US Model
Canadian Model
HCD-C70/C90
AEP Model
UK Model
E Model
Australian Model
Tourist Model
HCD-C70

Model Name Using Similar Mechanism	HCD-C50/C50U
CD Mechanism Type	CDM23B-5BD3
Base Unit Type	BU-5BD3

SPECIFICATIONS

Tuner/CD Player

Tuner Section

System FM stereo, FM/AM
superheterodyne tuner

FM tuner section

Tuning range 87.5 — 108 MHz
Antenna terminals 75 ohms unbalanced
Intermediate frequency 10.7 MHz

AM tuner section (US, CND)

Tuning range 530 — 1,710 kHz
(with the AM tuning interval
set at 10 kHz)
531 — 1,710 kHz
(with the AM tuning interval
at 9 kHz)
Antenna AM loop antenna,
external antenna terminals

Intermediate frequency 450 kHz

AM tuner section (AEP, UK, G, IT)

Tuning range AM: 531 — 1,602 kHz (G)
AM: 522 — 1,611 kHz (IT)
MW: 531 — 1,602 kHz (AEP, UK)
LW: 153 — 279 kHz (AEP, UK)
Antenna AM loop antenna,
external antenna terminals
Intermediate frequency 450 kHz

AM tuner section (E, EA, SP, AUS, JE)

Tuning range MW: 531 — 1,602 kHz
(with the MW tuning interval set at 9 kHz)
MW: 530 — 1,710 kHz
(with the MW tuning interval set at 10 kHz)
(except the model for Middle East)
SW: 5.95 — 17.90 MHz
Antenna AM loop antenna,
external antenna terminals
Intermediate frequency 450 kHz

CD Player Section

System Compact disc digital audio
system
Laser Semiconductor laser
Wavelength 780 — 790 nm
Outputs DIGITAL OPTICAL OUT
(optical output connector):
wave length 660 nm,
output level -18 dBm

— Continued on next page —

TUNER CD PLAYER
SONY®

Supplied accessories (Sold only by a set)

Remote Commander (1)
Sony SUM-3 (NS) batteries (2)
AM loop antenna (1)
FM antenna (1)
Flat cord (1)

Design and specifications subject to change
without notice.

Laser component in this product is
capable of emitting radiation exceeding
the limit for Class 1.

CLASS 1 LASER PRODUCT
LUOKAN 1 LASERLAITE
KLASS 1 LASERAPPARAT

This appliance is classified as a CLASS 1
LASER product. The CLASS 1 LASER
PRODUCT MARKING is located on the rear
exterior.

The following caution label is located inside
the unit.

CAUTION	: INVISIBLE LASER RADIATION WHEN OPEN. AVOID EXPOSURE TO BEAM.
ADVARSEL	: USYNLIG LASERSTRÅLING VED ÅBNING NÅR SIKKERHEDSÅFTRYDEDE ER UDE AF FUNKTION. UNNGÅ UDSÆTTELSE FOR STRÅLING.
VARO!	: AVATTAESSA JA SUOJALUKUTUS OHTETIÄESSÄ OLET ALTIITINA LASERSATEILYLLE.
VARNING	: LASERSTRÅLING NÅR DENNA DEL ÄR ÖPPNAD OCH SPÄRREN ÄR URÖPPAD.
ADVARSEL	: USYNLIG LASERSTRÅLING NÅR DEKSEL ÅPNES UNNGÅ EKSPONERING FOR STRÅLEN.

Notes on chip component replacement

- Never reuse a disconnected chip component.
- Notice that the minus side of a tantalum capacitor may be damaged by heat.

Flexible Circuit Board Repairing

- Keep the temperature of the soldering iron around 270 °C during repairing.
- Do not touch the soldering iron on the same conductor of the circuit board (within 3 times).
- Be careful not to apply force on the conductor when soldering or unsoldering.


SAFETY-RELATED COMPONENT WARNING !!

COMPONENTS IDENTIFIED BY SHADING AND MARK $\triangle$ ON THE SCHEMATIC DIAGRAMS, EXPLODED VIEWS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

ATTENTION AUX COMPOSANTS RELATIFS À LA SÉCURITÉ!!

LES COMPOSANTS IDENTIFIÉS PAR UNE TRAME ET PAR UNE MAPQUE $\triangle$ SUR LES SCHÉMAS DE PRINCIPE, LES VUES EXPLOSÉES ET LES LISTES DE PIÈCES CONT D'UNE IMPORTANCE CRITIQUE POUR LA SÉCURITÉ DU FONCTIONNEMENT. NE LES REMPLACER QUE PAR DES COMPOSANTS SONY DONT LE NUMÉRO DE PIÈCE EST INDIQUÉ DANS LE PRÉSENT MANUEL OU DANS DES SUPPLÉMENTS PUBLIÉS PAR SONY.

MODEL IDENTIFICATION — SPECIFICATION LABEL —



Note

CND : Canadian model
G : German model
IT : Italian model
EA : Saudi Arabia model
AUS : Australian model
SP : Singapore model
JE : Tourist model

SAFETY CHECK-OUT

After correcting the original service problem, perform the following safety checks before releasing the set to the customer: Check the antenna terminals, metal trim, "metallized" knobs, screws, and all other exposed metal parts for AC leakage. Check leakage as described below.

LEAKAGE

The AC leakage from any exposed metal part to earth ground and from all exposed metal parts to any exposed metal part having a return to chassis, must not exceed 0.5 mA (500 microamperes). Leakage current can be measured by any one of three methods.

1. A commercial leakage tester, such as the Simpson 229 or RCA WT-540A. Follow the manufacturers' instructions to use these instruments.
2. A battery-operated AC milliammeter. The Data Precision 245 digital multimeter is suitable for this job.
3. Measuring the voltage drop across a resistor by means of a VOM or battery-operated AC voltmeter. The "limit" indication is 0.75 V, so analog meters must have an accurate low-voltage scale. The Simpson 250 and Sanwa SH-63Trd are examples of a passive VOM that is suitable. Nearly all battery operated digital multimeters that have a 2V AC range are suitable. (See Fig. A)




Fig. A. Using an AC voltmeter to check AC leakage.

TABLE OF CONTENTS

<u>Section</u>	<u>Title</u>	<u>Page</u>	<u>Section</u>	<u>Title</u>	<u>Page</u>
SECTION 1.	SERVICE NOTE	5	6-6.	Printed Wiring Board	
			• Main Section		38
SECTION 2.	GENERAL		6-7.	Schematic Diagram	
Parts Identification		9	• Main Section		41
SECTION 3.	DISASSEMBLY		6-8.	Schematic Diagram	
3-1.	Removal of Case	11	• Panel Section		46
3-2.	Removal of Back Panel	11	6-9.	Printed Wiring Board	
3-3.	Removal of Main Board	11	• Panel Section		51
3-4.	Removal of Front Panel Assy	12	6-10.	Semiconductor Lead Layouts	53
3-5.	Removal of CD Mechanism Deck	12			
SECTION 4.	ELECTRICAL ADJUSTMENTS		SECTION 7.	EXPLODED VIEWS	
4-1.	Tuner Section Adjustments	13	7-1.	Case, Board Section	55
4-2.	CD Section Adjustments	15	7-2.	CD Mechanism Section 1 (CDM23B-5BD3)	56
			7-3.	CD Mechanism Section 2 (CDM23B-5BD3)	57
			7-4.	Optical Pick-up Section (BU-5BD3)	58
SECTION 5.	IC PIN FUNCTIONS		SECTION 8.	ELECTRICAL PARTS LIST	59
• IC701 Tuner/Timer Controller (TMP87CC70F-6129)		17			
• IC601 CD Master Controller (75518GF-127-3B9)		18			
• IC201 CD Mechanism Controller (μPD75516GF-431-3B9)		20			
SECTION 6.	DIAGRAMS				
6-1.	Circuit Boards Location	23			
6-2.	Block Diagram — Tuner Section —	24			
6-3.	Block Diagram — Display Section —	27			
6-4.	Schematic Diagram				
• Tuner Section		31			
6-5.	Printed Wiring Board				
• Tuner Section		35			

SECTION 1

SERVICING NOTE

• POWER SUPPLIED WHILE SERVICING

This unit does not have its own power supply. It operates on the power supplied from the deck/amplifier (DXA-C70/C90) used by this series. Therefore connect the amplifier when servicing the unit as in electrical repairs.

Power can also be supplied by connecting the "CDP/TC" connector of the conduction tool (PFJ-1). The following will be required to connect it.

J-2501-063-A

1-696-741-11 cord, (with connector)

1-751-469-11 cord, (with connector)

The connection to the tuner board can be checked with Pin 5 (FM-R CH) and Pin 6 (FL-L CH) of CN307.

• MEASURING THE TUNER/TCB011 BOARDS VOLTAGE

Prepare the following tools (extension cables) when measuring the voltages of the TUNER and TCB011 boards.

1) 4-pin extension cable (J-8000-026-A) × 3

2) 8-pin extension cable (J-8000-027-A) × 1

NOTES ON HANDLING THE OPTICAL PICK-UP BLOCK OR BASE UNIT

The laser diode in the optical pick-up block may suffer electrostatic break-down because of the potential difference generated by the charged electrostatic load, etc. on clothing and the human body.

During repair, pay attention to electrostatic break-down and also use the procedure in the printed matter which is included in the repair parts.



The flexible board is easily damaged and should be handled with care.

NOTES ON LASER DIODE EMISSION CHECK


The laser beam on this model is concentrated so as to be focused on the disc reflective surface by the objective lens in the optical pick-up block. Therefore, when checking the laser diode emission, observe from more than 30 cm away from the objective lens.

LASER DIODE AND FOCUS SEARCH OPERATION CHECK


Carry out the "S curve check" in "CD section adjustment" and check that the S curve waveform is output three times.




Disc Taking Out Procedures



- 1) Insert a thin stick into the hollow of the white block and move it in the arrow direction.
(When a disc is chucked, handle the unit as follows to avoid disc removal.)




- 2) Turn the pulley A in the arrow  direction and make sure that the disc tray moves in the arrow  direction. And further turn the pulley A until the tray aligns with other trays.



- 3) Open the front panel lid. Turn the pulley B to allow the stock, which has the disc tray, to go up and down until the disc inserted tray aligns with the front panel lid position .
- 4) Turn the pulley A in the arrow ○ direction to allow the disc inserted tray to be ejected. Take out the disc and turn the pulley A in the reverse direction to allow the disc inserted tray to align with other trays.

In case two or more trays have discs, repeat step 3) and 4).



※ 2 Initial setting procedures

Initial Setting Procedures

- 1) In case turning ON the system power supply allows the mechanism to work:
First, make sure that all discs have been taken out.

Open the disc No.1.



Turn OFF the system power supply.




Make sure that "OFF" appears on the CD display.



Blinking and character disappearing indicates setting completion.

- 2) In case turning ON the system power supply does not allow the mechanism to work:
Move the disc tray as shown in Fig.




- ※ Make sure that all trays are in the correct positions. Turn the pulley B in the arrow direction until it stops.

SECTION 2 GENERAL

This section is extracted from instruction manual.

Parts Identification

B




Tuner/CD Player Section

Tuner B

- 1 Remote control sensor
- 2 WAKE UP TIMER 1, 2 /CLOCK SET buttons
- 3 TIMER REC button
- 4 Display window
- 5 MEMORY/NEXT button
- 6 MODE button and TUNING/PRESET indicators
- 7 BAND selector
- 8 PRESET/TIMER +/- buttons
- 9 STEREO/MONO (stereo/monaural) button

Display

- 10 Timer indications
- 11 Tuner indications
- 12 MEMORY indication
- 13 Preset station number display
- 14 Frequency and clock display
- 15 Program source/recording equipment display for timer operation


C


CD Player C

- 1 Display window
- 2 Disc tray door
- 3 DISC 1 — 5 selectors and disc tray indicators
- 4 OPEN/CLOSE Δ buttons
- 5 CD operation buttons
 - : Stop button
 - ||: Pause button
 - ▷: Play button
 - [◀◀ ▶▶ ▶▶ ▶▶ ▶▶]: Manual search (when kept depressed)/Automatic Music Sensor (when pressed) buttons
- 6 REPEAT button
- 7 PLAY MODE buttons
 - PROGRAM button
 - SHUFFLE button
 - CONTINUE button
- 8 TIME/MEMO button
- 9 S.F.FILE (Sound Field File) button
- 10 CURSOR button
- 11 CHARACTER </> buttons
- 12 MEMO INPUT button
- 13 ERASE button

Display

- 14 CD playing mode indications
- 15 CD playing time display
 - Disc Memo display
- 16 S.F.FILE on/off indication
- 17 DISC MEMO on/off indication
- 18 CD editing mode indications
- 19 CD selection number display
- 20 Indicators for all track numbers on a CD


D


Remote Commander D


- 1 CLOCK DISPLAY button
- 2 DECK A/B selector
- 3 TUNER/EQ/CD numeric buttons function selector
- 4 P. FILE button
- 5 CD player operation buttons
- 6 CHECK button
- 7 MEMORY button
- 8 EQ button
- 9 SURROUND button
- 10 OFF button
- 11 CURSOR CONTROL buttons and EFFECT button
- 12 SLEEP button
- 13 SYSTEM POWER button
- 14 Cassette deck operation buttons
- 15 Tuner/equalizer/CD numeric buttons
- 16 BAND button
- 17 DISC 1 — 5 selectors
- 18 CLEAR button
- 19 DISC SKIP button
- 20 EDIT button
- 21 FUNCTION button
- 22 VOL +/- buttons

SECTION 3 DISASSEMBLY


3-1. REMOVAL OF CASE




3-2. REMOVAL OF BACK PANEL




3-3. REMOVAL OF MAIN BOARD



3-4. REMOVAL OF FRONT PANEL ASSY



3-5. REMOVAL OF CD MECHANISM DECK




SECTION 4 ELECTRICAL ADJUSTMENTS

4-1. Tuner Section Adjustments

FM SECTION


Note : The FM front-end is carefully adjusted at the factory and is supplied as one whole block for replacement.

Setting :



Carrier frequency : 98MHz
Modulation : 1kHz, 75kHz deviation
Output level : 1mV (60dBμ)

VOM
(DC range) 50μA



FM Discriminator Alignment (NULL Check)

BAND switch: FM

Procedure:

1. Supply a 1mV (60dBμ) 98MHz signal from the ANTENNA terminal.
2. Tune the set to 98MHz.
3. Adjust IFT51 for 0Vdc reading on the VOM.

Note : FM tuned indication lighting level adjustment should be made after FM discriminator alignment.

FM Tuned Indication Lighting Level Adjustment


BAND switch: FM

Procedure:

1. Supply a 17.8μV (25dBμ) (Except C70: G, IT model) or 12.5μV (22dBμ) (C70: G, IT models) 98MHz signal from the ANTENNA terminal.
2. Tune the set to 98MHz.
3. Adjust RV52 so that the **TUNED** light up.
4. Confirm that the **TUNED** light off with FM RF SSG output level set at -3dB.

MW SECTION

Setting :



MW Tuned Indication Lighting Level Adjustment

BAND switch: MW


Procedure:

1. Set loop antenna A so that the loop antenna B input level becomes 1mV (55dBμ).
2. Tune the set to 1,404kHz (9k step mode) (10k step mode : 1,490kHz).
3. Adjust the RV51 so that the **TUNED** light up.
4. Confirm that the **TUNED** light off with AM RF SG output level set at -3dB.

SW SECTION C70 : E, EA, AUS, SP, JE model

Setting :

AM RF signal generator




Note :

CND : Canadian model
G : German model
IT : Italian model
EA : Saudi Arabia model
AUS : Australian model
SP : Singapore model
JE : Tourist model

SW Tracking Adjustment

BAND switch: SW




Adjust for maximum reading on VTVM.

17MHz	CV1
7MHz	T1

Adjustment Location : TCB board.

SW OSC Voltage Adjustment

BAND switch: SW




Procedure:

1. Press TUNING (+, -) button for 5.95MHz.
Adjust T2 for 0.9–1.1V VOM reading.
2. Press the button for 17.9MHz.
Adjust CV2 for 8.3–8.7V reading.

Adjustment Location : TCB011 board.

[TCB011 BOARD] — Component side —



Except C70:US, CND/C90 model


4-2. CD Section Adjustments

CD SECTION

Note :

1. CD Block basically constructed to operate without adjustment. Therefore, check each item in order given.
2. Use YEDS-18 disc (3-702-101-01) unless otherwise indicated.
3. Use the oscilloscope with more than $10M\Omega$ impedance.
4. Clean an object lens by an applicator with neutral detergent when the signal level is low than specified value with the following checks.


S Curve Check



Procedure :

1. Connect oscilloscope to test point TP (FEO) on BD board.
2. Connect between test point TP (FES) and TP (VC) by lead wire.
3. Turn Power switch on.
4. Playback the disc (YEDS-18) and actuate the focus search. (actuate the focus search when disc table is moving in and out.)
5. Check the oscilloscope waveform (S curve) is symmetrical between A and B. And confirm peak to peak level within $3\pm 1V_{p-p}$.

S curve waveform




6. After check, remove the lead wire connected in step 2.

Note : • Try to measure several times to make sure that the ratio of A : B or B : A is more than 10 : 7.

- Take sweep time as long as possible and light up the brightness to obtain best waveform.

RF Level Check




Procedure :

1. Connect oscilloscope to test point TP (RFO) on BD board.
2. Turn Power switch on.
3. Put disc (YEDS-18) in and playback.
4. Confirm that oscilloscope waveform is clear and check RF signal level is correct or not.


Note :

Clear RF signal waveform means that the shape "◇" can be clearly distinguished at the center of the waveform.

RF signal waveform




E-F Balance Check



Procedure :

1. Connect test point TP (ADJ) on CD MAIN board to ground and TP (TES) to TP (VC) with lead wire.
2. Connect oscilloscope to test point TP (TEO) on BD board.
3. Turn Power switch on.
4. Put disc (YEDS-18) in and playback.
5. Confirm that the oscilloscope waveform is symmetrical on the top and bottom in relation to 0Vdc, and check this level.

Traverse oscilloscope




6. Remove the lead wire connected in step 1.

RF PLL Free-run Frequency Check

Procedure :

1. Connect frequency counter to test point (PLCK : IC202 ④) PIN with lead wire.



2. Turn Power switch on.
3. Confirm that reading on frequency counter is 4.3218MHz.

Focus/Tracking Gain

This gain has a margin, so even if it is slightly off.


There is no problem.

Therefore, do not perform, this adjustment.


Please note that it should be fixed to mechanical center position when you moved and do not know original position.

Adjustment Location:

【 BD BOARD 】 — CONDUCTOR SIDE —



【 CD MAIN BOARD 】 — CONDUCTOR SIDE —



SECTION 5

IC PIN FUNCTIONS

● **IC701 TUNER/TIMER CONTROLLER (TMP87CC70F-6129)**

The terminals work to control tuner section (IC21, 51), FL tube display and reading and writing of IC702 (preset data), etc. according to key input and signal from the remote controller.

Pin No.	Pin Name	I/O	Active	Function
1	HOLD	I	↓	HOLD detecting interrupt terminal
2	HOLD RESET	I	↑	HOLD resetting interrupt terminal
3				GND
4	IF NGOUT	O	H	IF count NG output (Not in use)
5	LED (TUNING)	O	H	TUNING LED ON
6	LED (PRESET)	O	H	PRESET LED ON
7	AUB IN	I	L	AUDIO BUS input
8	AUB OUT	O	L	AUDIO BUS output
9	TEST			GND
10	XT IN	I		Low frequency oscillator connection terminal (32kHz)
11	XT OUT	O		Low frequency oscillator connection terminal (32kHz)
12	RESET	I	L	Reset signal input
13	X IN	I		High frequency oscillator connection terminal (8MHz)
14	X OUT	O		High frequency oscillator connection terminal (8MHz)
15	VSS			GND
16				GND
17, 18				Not in use
19	SCK	O		PLL serial clock output
20	SI	I		PLL serial data input
21	SO	O		PLL serial data output
22				Not in use
23	CE	O	H	PLL chip enable
24				Not in use
25	FM/AM	O	L	TUNER (FM/AM) sound selection terminal
26	SUB SEL	O	L	Sub sound selection terminal (Not in use)
27	DUAL IND	I	L	Sound dual signal detection terminal (Not in use)
28	MONO			Not in use
29	MUTE OUT	O	L	MUTING output
30	SIGNAL IN	I	L	TUNED input
31	STEREO IN	I	L	STEREO input
32	SIRCS IN	I	L	SIRCS input
33	VDD			+5V
34 – 40		O		Not in use
41 – 49	G8 – G0	O	H	FL tube digit output
50 – 59	S0 – S9	O	H	FL tube segment output
60 – 65		O		Not in use
66	VKK			FL tube driving power supply
67 – 71	KI0 – KI4	I	H	Key input
72				Not in use
73, 74				Not in use
75 – 78	KO3 – KO0	O	H	Key output
79	SDA	I/O		Data input/output for EEPROM
80	SCL	O		Clock output for EEPROM

● **IC601 CD MASTER CONTROLLER (75518GF-127-3B9)**

This controller exchanges data with IC602 (CD FL driver) on the PANEL board and IC201 (CD mechanism controller) on the MAIN board. It has mainly feature related functions.

Pin No.	Pin Name	I/O	Function
1	KEY0	I	Key input port (A/D input)
2	AVREF	—	Reference voltage input pin of A/D converter (Connected to +5V)
3	VDD	—	} +5V power supply
4	VDD	—	
5		O	Not used (Open)
6	DRIVER RESET	O	Reset signal output for CD FL driver (IC602)
7	ON/OFF	O	+5V switch power supply (signal system) control “L”=OFF. “L” when ST function is on. “H” at other times.
8	Mecha-con RESET	O	Reset signal output for CD mechanism controller (IC201)
9		O	Not used (Open)
10	$\overline{CS}$	O	Latched output to CD FL driver (IC602)
11	AU BUS OUT	O	AU Bus output port
12	MREQ	O	Output of communication data read request to CD mechanism controller (IC201) (master request)
13	AU BUS/SIRCS	I	AU Bus/SIRCS selection. AU Bus=Fixed at “H”
14	TEST	I	Test mode pin. TEST=Fixed at “H”.
15	SUF. REP	I	Normally, SUF.REP=Fixed at “H”. By setting this pin to “L”, SHUFFLE, ALL-DISC, REP are possible.
16	D. SKIP	I	Sound field/EDIT (S332) function selection. Fixed at “H”. “H”: Sound field file. “L”: Edit
17		I	} Not used (Connected to +5V)
18		I	
19		I	
20		I	
21		I	
22		I	
23		I	
24	SACK	I	Input of communication ANSWER CODE from CD mechanism controller (IC201)
25		O	} Not used (Open)
26		O	
27		O	
28		O	
29	P53	O	Disc indicator (LED) orange (DISC 4)
30	P52	O	Disc indicator (LED) orange (DISC 3)
31	P51	O	Disc indicator (LED) orange (DISC 2)
32	P50	O	Disc indicator (LED) orange (DISC 1)
33	Vss	—	GND
34	P43	O	Disc indicator (LED) green (DISC 4)
35	P42	O	Disc indicator (LED) green (DISC 3)
36	P41	O	Disc indicator (LED) green (DISC 2)
37	P40	O	Disc indicator (LED) green (DISC 1)
38	P33	O	Disc indicator (LED) orange (DISC 5)
39	P32	O	Disc indicator (LED) green (DISC 5)
40	A SELECT	O	Output of A SELECT signal to INPUT SELECTOR (IC105)



Pin No.	Pin Name	I/O	Function
41	M/F	I/O	Signal indicating type of communication with CD mechanism controller (IC201) "H": Mechanism command "L": File command
42		O	Not used (Open)
43		O	
44		O	
45		O	
46		I	Not used (Connected to GND)
47		I	
48	OINT	I	Communication data read request (interruption request) signal from CD mechanism controller (IC201)
49	AU BUS IN	I	AU Bus input port (Interruption pin)
50		I	Not used (Connected to +5V)
51	DPDAT	O	Output of data to CD FL driver (IC602)
52	DPCK	O	Output of clock to CD FL driver (IC602)
53		I	Not used (Connected to GND)
54	Vss	—	GND
55	XT1		Not used (Connected to GND)
56	XT2		Not used (Open)
57	IC		Not used (Connected to GND)
58	X1	I	Pin connected for system clock (4.19 MHz) oscillator
59	X2	O	
60	RESET	I	System reset input. "L": Reset
61		O	Not used (Open)
62		O	
63		O	
64		O	
65	P133	O	
66	P132	O	
67	P131	O	
68	P130	O	
69	CMD3	I/O	Command data line with CD mechanism controller (IC201)
70	CMD2	I/O	
71	CMD1	I/O	
72	CMD0	I/O	
73	AVss	—	GND
74		I	Not used (Connected to GND)
75		I	
76		I	
77		I	
78	KEY3	I	Key input port (A/D input)
79	KEY2	I	
80	KEY1	I	

● **IC201 CD MECHANISM CONTROLLER (μ PD75516GF-431-3B9)**

This controller exchanges data with CXA1372AQ (RF signal processor, servo processor), CXD2500BQ (digital signal processor), MSM6538 (digital filter), 75518GF (CD master controller) of the CD section. It mainly controls the mechanism section.

Pin No.	Pin Name	I/O	Function
1			Open
2	AVDD		+5V power supply
3	VDD		
4	VDD		
5	ENCODER E3	I	Stocker position detection decoder input 3 *1
6	ENCODER E2	I	Stocker position detection decoder input 2 *1
7	ENCODER E1	I	Stocker position detection decoder input 1 *1
8	ENCODER E0	I	Stocker position detection decoder input 0 *1
9	D7	I/O	Input/output of data written in and read from SRAM (LH5160TA)
10	D6	I/O	
11	D5	I/O	
12	D4	I/O	
13	D3	I/O	
14	D2	I/O	
15	D1	I/O	
16	D0	I/O	
17	GFS	I	Input of GFS signal from digital signal processor (CXD2500BQ) L: NG. H: OK
18	SENSE	I	Input of SENS signal from digital signal processor (CXD2500BQ)
19	DOWN SW	I	Input of down of up/down switch
20	UP SW	I	Input of up of up/down switch
21	A11	O	Output of address to SRAM (LH5160TA)
22	A10	O	
23	A9	O	
24	A8	O	
25		I	Not used
26	LD ON	O	Optical pickup block laser diode control output H: ON. L: OFF
27	WE	O	Output of write enable to SRAM
28	A12	O	Output of address to SRAM (LH5160TA)
29	A7	O	
30	A6	O	
31	A5	O	
32	A4	O	
33	GND		GND
34	A3	O	Output of address to SRAM (LH5160TA)
35	A2	O	
36	A1	O	
37	A0	O	
38	QINT	O	Output of communication data read request to CD master controller (75518GF)
39	M/F	I	Signal indicating type of communication data from CD master controller (75518GF) H: Mechanism command. L: File command
40	SACK	O	Output of communication answer code to CD master controller (75518GF)

Pin No.	Pin Name	I/O	Function
41	MREQ	I	Input of communication data read request from CD master controller (75518GF) (master request)
42	CMD3	I/O	Input/output of data 3 of communication with CD master controller (75518GF)
43	CMD2	I/O	Input/output of data 2 of communication with CD master controller (75518GF)
44	CMD1	I/O	Input/output of data 1 of communication with CD master controller (75518GF)
45	CMD0	I/O	Input/output of data 0 of communication with CD master controller (75518GF)
46	CHIN	I	Input of track jump count from RF/servo IC (CXA1372AQ)
47	FOK	I	Input of focus OK signal from RF/servo IC (CXA1372AQ). H: OK
48	SCOR	I	Input of sub code sync S0+S1 detection from digital signal processor (CXD2500BQ)
49	STOCK IN	I	Input of tray position (STOCK IN) detection *2
50	SUBQ	I	Input of sub code Q data from digital signal processor (CXD2500BQ)
51	GND		GND
52	SQCK	O	Output of sub code Q data read clock to digital signal processor (CXD2500BQ)
53	ADJ	I	Test mode input. Fixed at level H (Test mode is set when set to level L)
54	GND		GND
55	XT1	I	Not used (Connected to GND)
56	XT2	O	Not used (Open)
57	GND		GND
58	X1	I	} Pin connected for system clock (4.19 MHz) oscillator
59	X2	O	
60	RESET	I	Input of reset from CD master controller (75518GF). L: Reset
61	D/F LATCH	O	Output of serial data latch signal to digital filter (MSM6538)
62	DSP LATCH	O	Output of serial data latch signal to digital signal processor (CXD2500BQ)
63	CLK	O	Output of serial clock to digital signal processor (CXD2500BQ) and digital filter (MSM6538)
64	DATA	O	Output of serial data to digital signal processor (CXD2500BQ) and digital filter (MSM6538)
65	DFCTSW	O	RF/servo IC (CXA1372AQ) DEFECT circuit ON/OFF control output. L: ON. H: OFF Stops disc scratch detection during focus search (Set to H)
66	MUTE	O	CD audio output mute signal. H: Mute
67	CLAMP M3M	O	} Clamp motor control signal *3
68	CLAMP M3P	O	
69	UP/DOWN M2M	O	} Stocker motor control signal *4
70	UP/DOWN M2P	O	
71	LOADING M1M	O	} Loading motor control signal *5
72	LOADING M1P	O	
73	A GND		GND
74	STOK OK	I	Tray position detection input. L: Stocker UP/DOWN possible position *2
75	DISC SENS	I	Disc sensor input. H: Disc present. L: No disc
76	DISC TABLE IN SW	I	Loading-in switch input
77	DISC TABLE OUT SW	I	Loading-out switch input
78	TEST	I	Test mode input. Fixed at level H. (Test mode is set when set to level L)
79	AF ADJ	I	Test mode input. Fixed at level H. (Test mode is set when set to level L)
80			Not used (Open)



*3

	UP	DOWN	BRAKE
CLAMP M3P	H	L	H
CLAMP M3M	L	H	H

*4



	UP	DOWN	BRAKE
UP/DOWN M2P	H	L	H
UP/DOWN M2M	L	H	H

*5





	OUT	IN	BRAKE
LOADING M1P	H	L	H
LOADING M1M	L	H	H

SECTION 6 DIAGRAMS

6-1. CIRCUIT BOARDS LOCATION




6-2. BLOCK DIAGRAM—TUNER SECTION—




Abbreviation
CNB: Canadian model
G: German model
IT: Italian model
EA: Saudi Arabia model
SP: Singapore model
AUS: Australian model
JE: Tourist model

Signal path
FM
MW

IC21 LC7218M

[illegible]

-  : B+ Line
-  : B- Line
-  : adjustment for repair.
- Voltage and waveforms are dc with respect to ground under no-signal conditions.
 - no mark : FM
- Voltages are taken with a VOM (Input impedance 10 Ω). Voltage variations may be noted due to normal production tolerances.
- Signal path.
 -  : FM




CND : Canadian model
G : German model
IT : Italian model
EA : Saudi Arabia model
AUS : Australian model
SP : Singapore model
JE : Tourist model

6-5. PRINTED WIRING BOARD

• TUNER SECTION

• See page 23 for Circuit Boards Location and see page 53, 54 for Semiconductor Lead Layouts.



• Semiconductor Location
• C70:US,CND,E,EA,
AUS,SP,JE/C90 MODEL

Ref. No.	Location
D1	D-7
D21	D-5
D51	D-2
IC21	C-6
IC51	C-4
Q1	B-4
Q3	C-4
Q4	D-6
Q5	E-6
Q6	D-8
Q21	C-5
Q22	C-6
Q23	C-7
Q51	C-2
Q52	C-2
Q53	B-3

• Semiconductor Location
• C70:AEP, UK, G, IT MODEL

Ref. No.	Location
D21	D-13
D51	D-11
IC21	C-14
IC51	C-12
Q1	B-12
Q2	C-12
Q3	C-13
Q4	E-14
Q5	D-16
Q6	D-14
Q7	D-16
Q21	C-13
Q22	C-15
Q23	C-15
Q24	C-15
Q25	C-16
Q51	C-11
Q52	C-10
Q53	B-11

Notes on printed wiring boards:

- : parts extracted from the components side.
- △ : internal component.
- : panel designation.
- : Through hole.
- ⋯ : Pattern on the side which is seen.
- ⋯ : Pattern of the rear side.

CND : Canadian model
G : German model
IT : Italian model
EA : Saudi Arabia model
AUS : Australian model
SP : Singapore model
JE : Tourist model


6-6. PRINTED WIRING BOARD


- MAIN SECTION
- See page 23 for Circuit Boards Location and see page 53, 54 for Semiconductor Lead Layouts.

• Semiconductor Location


Ref. No.	Location	Ref. No.	Location
D101	F-6	Q101	E-10
D102	F-6	Q101(BD)	C-1
D103	F-6	Q103	E-11
D104	F-6	Q104	C-9
D105	G-6	Q105	E-13
D106	G-6	Q106	C-12
D107	G-6	Q107	D-13
D108	G-6	Q108	E-9
D109	D-11	Q109	D-10
D110	C-8	Q110	C-10
D111	D-8	Q111	C-11
D112	C-8	Q112	D-10
D113	D-7		
D114	F-9		
D115	F-9		
D116	E-10		
D117	D-10		
D118	D-10		
D205	F-12		
D206	J-13		
D207	J-14		
IC101(BD)	B-2		
IC101	E-13		
IC102(BD)	B-3		
IC102	E-8		
IC103	C-9		
IC104	H-9		
IC105	H-6		
IC106	J-5		
IC201	H-13		
IC202	H-11		
IC203	H-9		
IC204	H-8		
IC205	I-7		
IC207	F-13		
IC208	E-14		
IC209	I-14		
IC210	I-13		
IC211	I-11		
IC401	G-21		
IC501	B-18		
IC601	G-19		


- Note:
- : parts extracted from the components side.
 - △ : internal component.
 - : panel designation.
 - : Through hole.
 - : Pattern on the side which is seen.
 - : Pattern on the rear side.





CDM MOTOR BOARD (H)	CDM MOTOR BOARD (B)	CDM MOTOR BOARD (G)	CDM MOTOR BOARD (F)	CDM MOTOR BOARD (E)	CDM MOTOR BOARD (C)	CDM MOTOR BOARD (A)	CDM MOTOR BOARD (D)






6-9. PRINTED WIRING BOARD

• PANEL SECTION

• See page 23 for Circuit Boards Location and see page 53, 54 for Semiconductor Lead Layouts.



• Semiconductor Location

Ref. No.	Location
D601	F-6
D620	G-3
D621	G-3
D622	F-3
D623	E-3
D624	H-3
D625	G-3
D626	G-3
D627	F-3
D628	E-3
D629	H-3
D630	G-9
D701	C-6
D702	C-5
D703	C-6
D704	C-5
D706	C-5
D707	C-5
D708	C-6
D710	C-2
D711	C-3
D712	D-9
D716	D-7
D717	D-10
D718	D-10
IC601	F-4
IC602	F-8
IC603	F-10
IC701	C-7
IC702	D-5
IC703	D-6
IC704	D-8
IC705	D-11
Q601	F-6
Q604	H-9
Q612	F-9
Q613	F-9
Q701	D-4
Q702	D-4
Q706	D-6
Q707	D-7


Note:

- : parts extracted from the components side.
- △ : internal component.
- : panel designation
- : Through hole.
- ⋯ : Pattern on the side which is seen.
- ⋯ : Pattern of the rear side.


CND : Canadian model
G : German model
IT : Italian model
EA : Saudi Arabia model
AUS : Australian model
SP : Singapore model
JE : Tourist model

6-10. SEMICONDUCTOR LEAD LAYOUTS


BA6418N




CXA1372AQ




CXD2500BQ
TMP87CC70F-6129
μPD75516GF-461-3B9




GP1F32T




GP1U90XB




LA1851NM




LA5601




LA6532M




LC7218M




LH5160N-10L




MC14052BF




MC14093BF




MSM6538-01GS-VKR1




M5F78M07L
TA7805S




M5218FP
M5218AFP




M5290FP




M66004M4FP




ON1023-S




PCM-67U-B




PST600D-T
PST600G-T




TA79005S




X24C01S



75518GF-127-3B9




TPS626




2SA1678
2SA1602-F
2SC2814-F4
2SC3398
2SC4154-F
2SC4398
2SC4666B
DTC144EK




2SB1094-LK
2SB1375-LC




2SD1615A-GP




2SD2012




2SK208GR3




DCB010



EC10DS2




KV1560NT




MA8056
1SS352




SEL2410E-C-TP6
SEL5220S-TH8C




TLN117




UZM11X



UZP-30BB
UZP-4.3BA
UZP-8.2BB



1SS226



SECTION 7

EXPLODED VIEWS

NOTE:

- -XX, -X mean standardized parts, so they may have some difference from the original one.
- Color Indication of Appearance Parts
Example:
KNOB, BALANCE (WHITE) ... (RED)
↑ ↑
Parts color Cabinet's color
- Hardware (# mark) list is given in the last of this parts list.


- Items marked " * " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- The mechanical parts with no reference number in the exploded views are not supplied.
- CND : Canadian model
- G : German model
- IT : Italian model

- JE : Tourist model
- EA : Saudi Arabia model
- AUS : Australian model
- SP : Singapore model

The components identified by mark Δ or dotted line with mark Δ are critical for safety.
Replace only with part number specified.


Les composants identifiés par une marque Δ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

7-1. CASE, BOARD SECTION




Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
1	X-4943-907-1	PANEL ASSY, FRONT (C70:US, CND)		* 12	4-962-178-01	HOLDER (FLEXIBLE)	
1	X-4943-908-1	PANEL ASSY, FRONT (C70:E, AUS, EA, SP, JE)		13	3-831-441-XX	CUSHION, SPEAKER	
1	X-4943-910-1	PANEL ASSY, FRONT (C90)		* 14	A-4365-193-A	MAIN BOARD, COMPLETE (C70:US, CND/C90)	
1	X-4943-927-1	PANEL ASSY, FRONT (C70:AEP, UK, G, IT)		* 14	A-4365-198-A	MAIN BOARD, COMPLETE (C70:AEP, UK)	
2	4-930-336-31	FOOT (FELT)		* 14	A-4365-200-A	MAIN BOARD, COMPLETE (C70:E, AUS, EA, SP, JE)	
3	4-933-134-01	SCREW (+PTPH M2.6X6)		* 14	A-4365-201-A	MAIN BOARD, COMPLETE (C70:G, IT)	
4	4-959-206-01	LID (LOADING)		15	1-751-690-11	WIRE (FLAT TYPE) (21 CORE)	
5	4-959-207-01	SPRING (CLOSE)		16	1-751-659-11	WIRE (FLAT TYPE) (22 CORE)	
6	4-932-882-11	KNOB (HP. VOL)		17	1-751-688-11	WIRE (FLAT TYPE) (13 CORE)	
		(C70:AEP, UK, E, AUS, G, IT, EA, SP, JE)		* 18	1-649-358-11	TUNER BOARD (C70:US, CND, E, AUS, SP, JE/C90)	
* 7	1-649-225-11	MICROPHONE BOARD		* 18	1-649-359-11	TUNER BOARD (C70:AEP, UK, G, IT)	
		(C70:AEP, UK, E, AUS, G, IT, EA, SP, JE)		* 19	A-4303-342-A	TCB011 BOARD, COMPLETE (C70:US, CND/C90)	
* 8	A-4365-203-A	PANEL BOARD, COMPLETE (C70:US, CND/C90)		* 19	A-4303-343-A	TCB011 BOARD, COMPLETE (C70:AEP, UK)	
* 8	A-4365-204-A	PANEL BOARD, COMPLETE (C70:AEP, UK)		* 19	A-4303-344-A	TCB011 BOARD, COMPLETE (C70:G, IT)	
* 8	A-4365-205-A	PANEL BOARD, COMPLETE		* 19	A-4303-345-A	TCB011 BOARD, COMPLETE	
		(C70:E, AUS, EA, SP, JE)				(C70:E, EA, AUS, JE, SP)	
* 8	A-4365-206-A	PANEL BOARD, COMPLETE (C70:IT)		* 20	4-960-270-01	PANEL, BACK	
* 8	A-4365-210-A	PANEL BOARD, COMPLETE (C70:G)				(C70:US, CND, E, AUS, EA, SP, JE/C90)	
9	4-951-620-01	SCREW (2.6X8), +BVTP		* 20	4-960-270-11	PANEL, BACK (C70:AEP, UK, G, IT)	
10	3-363-099-01	SCREW (CASE 3 TP2)		* 21	4-962-179-02	HOLDER (PCB)	
* 11	4-960-313-61	CASE					

**7-2. CD MECHANISM SECTION 1
(CDM23B-5BD3)**



Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
51	4-954-649-01	SHAFT (ST-L)		* 71	4-954-621-01	STOPPER (TB)	
52	4-954-644-01	BRACKET (STOCKER L)		* 72	1-645-607-11	CDM MOTOR BOARD (A-H)	
53	4-954-638-01	TABLE, DISK		* 73	4-954-631-01	SHAFT (SL GUIDE)	
54	4-954-651-01	EMBLEM (TABLE)		* 74	4-954-623-01	FULCRUM (BU)	
55	4-954-651-11	EMBLEM (TABLE)		75	4-955-575-01	SPRING (BU), COMPRESSION	
56	4-954-651-21	EMBLEM (TABLE)		* 76	X-4942-941-1	BRACKET (SL-A) ASSY	
57	4-954-651-31	EMBLEM (TABLE)		77	4-929-762-01	YOKE, CHUCKING	
58	4-954-651-41	EMBLEM (TABLE)		78	1-452-676-11	MAGNET	
59	4-954-639-01	GUIDE (TB)		79	4-954-650-01	HOLDER (MG)	
* 60	4-954-648-01	SHAFT (TABLE GUIDE)		80	4-955-230-01	PULLEY (CHUCKING)	
61	4-954-645-01	GUIDE (ST-RF)		* 81	X-4942-942-1	HOLDER (BU) ASSY	
62	4-954-646-01	GUIDE (ST-RR)		82	4-954-625-01	GEAR (CDM)	
* 63	X-4942-943-1	BRACKET (ST-B) ASSY		83	3-372-516-01	PULLEY (LOADING)	
64	4-954-628-01	FLANGE (PULLEY)		84	4-954-624-01	BELT (CDM)	
65	4-954-630-01	SLIDER (TB)		* 85	A-4660-264-A	BRACKET (SL-B) ASSY	
66	4-954-634-01	BELT (SL)		* 86	4-955-890-01	SCREW (3X6)	
67	4-954-629-01	PULLEY (SL)		87	4-955-231-01	SPACER (MG)	
68	4-933-134-01	SCREW (+PTPH M2. 6X6)		88	3-558-708-21	WASHER, STOPPER	
69	3-669-595-00	WASHER (2), STOPPER		89	4-955-890-01	SCREW (3X6)	
70	4-954-627-01	GEAR (SL)		M103	A-4660-232-A	MOTOR (CDM) ASSY (LOADING)	


7-3. CD MECHANISM SECTION 2
(CDM23B-5BD3)



Ref.No.	Part No.	Description
101	X-4942-939-1	SLIDER (ST-L) ASSY
102	3-558-708-21	WASHER, STOPPER
103	4-954-625-01	GEAR (CDM)
104	3-372-517-01	GEAR (LOADING)
105	4-954-624-01	BELT (CDM)
106	3-372-516-01	PULLEY (LOADING)
107	4-954-636-01	GEAR (E)
108	3-681-678-00	WASHER, SLIT
* 109	1-645-607-11	CDM MOTOR BOARD (A-H)
* 110	4-954-633-01	GUIDE (TB-LR)
* 111	4-954-621-01	STOPPER (TB)

Ref.No.	Part No.	Description
112	X-4942-940-1	SLIDER (ST-R) ASSY
* 113	X-4942-937-1	CHASSIS (CDM) ASSY
114	4-954-637-01	PULLEY (BU)
115	4-954-635-01	BELT (BU)
116	4-955-168-01	SPRING, TENSION
* 117	4-954-632-02	LEVER (JOINT)
118	A-4660-167-A	SLIDER (BU CAM) ASSY
119	4-928-473-01	INSULATOR
M104	A-4660-232-A	MOTOR (CDM) ASSY (UP/DOWN)
M105	A-4660-232-A	MOTOR (CDM) ASSY (CLAMP)
S102	1-466-819-11	ENCODER, ROTARY

7-4. OPTICAL PICK-UP SECTION (BU-5BD3)



The components identified by mark  or dotted line with mark  are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque  sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

Ref. No.	Part No.	Description
151	4-917-565-01	SHAFT, SLED
152	4-933-126-01	INSULATOR (A)
153	4-917-567-01	GEAR (M)
154	4-917-564-01	GEAR (P), FLATNESS
 155	8-848-144-11	DEVICE, OPTICAL KSS-240A
156	1-575-001-11	WIRE, FLAT TYPE (12 CORE)

Remark	Ref. No.	Part No.	Description	Remark
	* 157	A-4617-371-A	BD BOARD, COMPLETE	
	158	1-751-597-11	WIRE (FLAT TYPE) (22 CORE)	
	M101	X-4917-523-3	MOTOR ASSY, DISK (SPINDLE)	
	M102	X-4917-504-1	MOTOR ASSY (SLED)	
	S101	1-572-085-11	SWITCH LEAF (LIMIT)	

SECTION 8

ELECTRICAL PARTS LIST

BD

NOTE:

The components identified by mark Δ or dotted line with mark Δ are critical for safety.
Replace only with part number specified.

Les composants identifiés par une marque Δ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

When indicating parts by reference number, please include the board name.

- Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- -XX, -X mean standardized parts, so they may have some difference from the original one.
- RESISTORS
All resistors are in ohms
METAL: Metal-film resistor
METAL OXIDE: Metal Oxide-film resistor
F : nonflammable
- Color Indication of Appearance Parts Example:
KNOB, BALANCE (WHITE) ... (RED)
 ↑ ↑
 Parts color Cabinet's color
- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

- SEMICONDUCTORS
In each case, u: μ , for example:
uA...: μ A..., uPA...: μ PA..., uPB...: μ PB...,
uPC...: μ PC..., uPD...: μ PD...
- CAPACITORS
uF : μ F
- COILS
uH : μ H
- CND : Canadian model
- G : German model
- IT : Italian model
- EA : Saudi Arabia model
- AUS : Australian model
- SP : Singapore model
- JE : Tourist model
- Hardware (# mark) list is given in the last of this parts list.

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
*	A-4617-371-A	BD BOARD, COMPLETE *****				< JUMPER RESISTOR >	
		< CAPACITOR >		JR101	1-216-295-00	METAL CHIP 0 5% 1/10W	
C101	1-163-038-00	CERAMIC CHIP 0.1uF	25V	JR102	1-216-295-00	METAL CHIP 0 5% 1/10W	
C102	1-163-989-11	CERAMIC CHIP 0.033uF 10%	25V			< MOTOR >	
C103	1-126-163-11	ELECT 4.7uF 20%	50V	M101	X-4917-523-3	MOTOR, DISK ASSY (SPINDLE)	
C104	1-163-038-00	CERAMIC CHIP 0.1uF	25V	M102	X-4917-504-1	MOTOR, ASSY (SLED)	
C105	1-126-154-11	ELECT 47uF 20%	6.3V			< TRANSISTOR >	
C106	1-126-154-11	ELECT 47uF 20%	6.3V	Q101	8-729-901-01	TRANSISTOR DTC144EK	
C107	1-126-154-11	ELECT 47uF 20%	6.3V			< RESISTOR >	
C108	1-163-038-00	CERAMIC CHIP 0.1uF	25V	R101	1-216-097-00	METAL CHIP 100K 5% 1/10W	
C109	1-163-038-00	CERAMIC CHIP 0.1uF	25V	R102	1-216-095-00	METAL CHIP 82K 5% 1/10W	
C110	1-163-989-11	CERAMIC CHIP 0.033uF 10%	25V	R103	1-216-091-00	METAL CHIP 56K 5% 1/10W	
C111	1-131-367-00	TANTALUM 22uF 10%	20V	R104	1-216-099-00	METAL CHIP 120K 5% 1/10W	
C112	1-164-232-11	CERAMIC CHIP 0.01uF	50V	R105	1-216-069-00	METAL CHIP 6.8K 5% 1/10W	
C113	1-164-232-11	CERAMIC CHIP 0.01uF	50V	R106	1-216-061-00	METAL CHIP 3.3K 5% 1/10W	
C114	1-164-161-11	CERAMIC CHIP 0.0022uF 10%	100V	R107	1-216-114-00	METAL GLAZE 510K 5% 1/10W	
C115	1-164-161-11	CERAMIC CHIP 0.0022uF 10%	100V	R108	1-216-105-00	METAL CHIP 220K 5% 1/10W	
C117	1-163-038-00	CERAMIC CHIP 0.1uF	25V	R109	1-216-061-00	METAL CHIP 3.3K 5% 1/10W	
C118	1-163-038-00	CERAMIC CHIP 0.1uF	25V	R110	1-216-049-00	METAL CHIP 1K 5% 1/10W	
C119	1-164-161-11	CERAMIC CHIP 0.0022uF 10%	100V	R111	1-216-049-00	METAL CHIP 1K 5% 1/10W	
C120	1-163-989-11	CERAMIC CHIP 0.033uF 10%	25V	R112	1-216-083-00	METAL CHIP 27K 5% 1/10W	
C151	1-163-019-00	CERAMIC CHIP 0.0068uF 10%	50V	R113	1-216-071-00	METAL CHIP 8.2K 5% 1/10W	
C152	1-163-038-00	CERAMIC CHIP 0.1uF	25V	R114	1-216-105-00	METAL CHIP 220K 5% 1/10W	
C153	1-163-006-11	CERAMIC CHIP 560PF 10%	50V	R152	1-216-073-00	METAL CHIP 10K 5% 1/10W	
C154	1-164-161-11	CERAMIC CHIP 0.0022uF 10%	100V	R153	1-216-085-00	METAL CHIP 33K 5% 1/10W	
C155	1-163-023-00	CERAMIC CHIP 0.015uF 5%	50V	R154	1-216-085-00	METAL CHIP 33K 5% 1/10W	
C171	1-163-038-00	CERAMIC CHIP 0.1uF	25V	R155	1-216-093-00	METAL CHIP 68K 5% 1/10W	
C172	1-163-038-00	CERAMIC CHIP 0.1uF	25V	R156	1-216-081-00	METAL CHIP 22K 5% 1/10W	
C173	1-163-038-00	CERAMIC CHIP 0.1uF	25V	R157	1-216-079-00	METAL CHIP 18K 5% 1/10W	
C174	1-163-038-00	CERAMIC CHIP 0.1uF	25V	R158	1-216-079-00	METAL CHIP 18K 5% 1/10W	
		< CONNECTOR >		R159	1-216-079-00	METAL CHIP 18K 5% 1/10W	
CN101	1-568-796-11	SOCKET, CONNECTOR 22P		R160	1-216-049-00	METAL CHIP 1K 5% 1/10W	
CN102	1-568-795-11	SOCKET, CONNECTOR 12P		R171	1-216-001-00	METAL CHIP 10 5% 1/10W	
		< IC >		R172	1-216-001-00	METAL CHIP 10 5% 1/10W	
IC101	8-752-053-73	IC CXA1372AQ		R173	1-216-001-00	METAL CHIP 10 5% 1/10W	
IC102	8-759-822-36	IC LA6532M		R174	1-216-001-00	METAL CHIP 10 5% 1/10W	

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
		< VARIABLE RESISTOR >					
RV101	1-238-600-11	RES, ADJ, CARBON 10K		*	A-4365-193-A	MAIN BOARD, COMPLETE (C70:US, CND/C90)	
RV102	1-238-600-11	RES, ADJ, CARBON 10K				*****	
		< SWITCH >		*	A-4365-198-A	MAIN BOARD, COMPLETE (C70:AEP, UK)	

S101	1-572-085-11	SWITCH, LEAF (LIMIT IN)		*	A-4365-200-A	MAIN BOARD, COMPLETE	

						(C70:E, AUS, EA, SP, JE)	
*****				*	A-4365-201-A	MAIN BOARD, COMPLETE (C70:G, IT)	
*	1-645-607-11	CDM MOTOR BOARD (A-H)				*****	

		< CAPACITOR >		*	3-309-144-21	HEAT SINK	
C101	1-164-159-11	CERAMIC 0.1uF	50V	*	4-870-539-00	PLATE, GROUND	
C102	1-164-159-11	CERAMIC 0.1uF	50V	*	4-880-403-11	HEAT SINK	
C103	1-164-159-11	CERAMIC 0.1uF	50V	*	4-963-010-01	PLATE, SHIELD	
					7-682-548-04	SCREW +BVT 3X8 (S)	
		< CONNECTOR >					
* CN105	1-568-934-11	PIN, CONNECTOR 7P				< CAPACITOR >	
* CN106	1-568-954-11	PIN, CONNECTOR 5P		C101	1-124-119-00	ELECT 330uF	20% 16V
		< IC >		C102	1-124-894-11	ELECT 6800uF	20% 16V
IC401	8-759-071-52	IC ON1023-S		C105	1-164-346-11	CERAMIC CHIP 1uF	16V
IC601	8-759-071-52	IC ON1023-S		C106	1-164-161-11	CERAMIC CHIP 0.0022uF	10% 100V
				C107	1-124-902-00	ELECT 0.47uF	20% 50V
		< MOTOR >		C108	1-124-443-00	ELECT 100uF	20% 10V
M103	A-4660-232-A	MOTOR (CDM) ASSY (LOADING)		C109	1-124-443-00	ELECT 100uF	20% 10V
M104	A-4660-232-A	MOTOR (CDM) ASSY (UP/DOWN)		C110	1-163-038-00	CERAMIC CHIP 0.1uF	25V
M105	A-4660-232-A	MOTOR (CDM) ASSY (CLAMP)		C111	1-126-101-11	ELECT 100uF	20% 16V
				C112	1-124-915-11	ELECT 10uF	20% 63V
		< RESISTOR >		C113	1-124-915-11	ELECT 10uF	20% 63V
R401	1-247-811-31	CARBON 150 5% 1/4W		C114	1-124-477-11	ELECT 47uF	20% 25V
R402	1-249-429-11	CARBON 10K 5% 1/4W		C117	1-124-915-11	ELECT 10uF	20% 63V
R601	1-247-811-31	CARBON 150 5% 1/4W		C120	1-124-478-11	ELECT 100uF	20% 25V
R602	1-249-429-11	CARBON 10K 5% 1/4W		C121	1-124-478-11	ELECT 100uF	20% 25V
		< SWITCH >		C122	1-124-485-11	ELECT 330uF	20% 35V
S101	1-571-300-21	SWITCH, ROTARY (BU UP/DOWN)		C123	1-126-101-11	ELECT 100uF	20% 16V
S103	1-692-080-11	SWITCH, PUSH (1 KEY) (TRAY OUT)		C124	1-126-101-11	ELECT 100uF	20% 16V
S104	1-692-080-11	SWITCH, PUSH (1 KEY) (TRAY IN)		C125	1-124-915-11	ELECT 10uF	20% 63V
*****				C126	1-124-122-11	ELECT 100uF	20% 50V
				C127	1-163-038-00	CERAMIC CHIP 0.1uF	25V
				C128	1-163-038-00	CERAMIC CHIP 0.1uF	25V
				C129	1-163-038-00	CERAMIC CHIP 0.1uF	25V
				C130	1-163-038-00	CERAMIC CHIP 0.1uF	25V
				C131	1-124-915-11	ELECT 10uF	20% 63V
				C132	1-124-903-11	ELECT 1uF	20% 50V
				C133	1-124-903-11	ELECT 1uF	20% 50V
				C141	1-163-117-00	CERAMIC CHIP 100PF	5% 50V
				C142	1-163-117-00	CERAMIC CHIP 100PF	5% 50V
				C151	1-163-038-00	CERAMIC CHIP 0.1uF	25V
				C152	1-163-038-00	CERAMIC CHIP 0.1uF	25V
				C213	1-164-346-11	CERAMIC CHIP 1uF	16V
				C214	1-163-038-00	CERAMIC CHIP 0.1uF	25V

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
C215	1-163-038-00	CERAMIC CHIP 0.1uF	25V	< CONNECTOR >			
C216	1-125-486-11	DOUBLE LAYERS 0.22F	5.5V	CN201	1-750-923-31	HOUSING, CONNECTOR(PC BOARD) 15P	
C217	1-163-038-00	CERAMIC CHIP 0.1uF	25V	* CN202	1-565-561-11	PIN, CONNECTOR 3P (AU BUS)	
C218	1-163-251-11	CERAMIC CHIP 100PF	5% 50V	CN203	1-569-495-11	SOCKET, CONNECTOR 9P (SYSTEM CONTROL)	
C219	1-124-915-11	ELECT 10uF	20% 63V	* CN205	1-568-934-11	PIN, CONNECTOR 7P	
C220	1-163-809-11	CERAMIC CHIP 0.047uF	10% 25V	CN206	1-506-468-11	PIN, CONNECTOR 3P	
C221	1-163-145-00	CERAMIC CHIP 0.0015uF	5% 50V	CN207	1-506-468-11	PIN, CONNECTOR 3P	
C222	1-164-346-11	CERAMIC CHIP 1uF	16V	* CN208	1-568-951-11	PIN, CONNECTOR 2P	
C223	1-136-173-00	FILM 0.47uF	5% 50V	CN209	1-506-469-11	PIN, CONNECTOR 4P	
C224	1-136-153-00	FILM 0.01uF	5% 50V	* CN210	1-573-264-11	PIN, CONNECTOR 5P	
C227	1-164-346-11	CERAMIC CHIP 1uF	16V	* CN211	1-764-108-11	CONNECTOR, FFC 22P	
C228	1-163-038-00	CERAMIC CHIP 0.1uF	25V	CN212	1-568-838-11	SOCKET, CONNECTOR 21P	
C229	1-163-227-11	CERAMIC CHIP 10PF	0.5PF 50V	* CN213	1-564-338-00	PIN, CONNECTOR 4P	
C230	1-163-227-11	CERAMIC CHIP 10PF	0.5PF 50V	(C70:AEP, UK, E, AUS, G, IT, EA, SP, JE)			
C232	1-164-346-11	CERAMIC CHIP 1uF	16V	< DIODE >			
C233	1-164-346-11	CERAMIC CHIP 1uF	16V	D101	8-719-210-33	DIODE EC10DS2	
C236	1-163-038-00	CERAMIC CHIP 0.1uF	25V	D102	8-719-210-33	DIODE EC10DS2	
C237	1-163-038-00	CERAMIC CHIP 0.1uF	25V	D103	8-719-210-33	DIODE EC10DS2	
C238	1-124-126-00	ELECT 47uF	20% 10V	D104	8-719-210-33	DIODE EC10DS2	
C239	1-124-126-00	ELECT 47uF	20% 10V	D105	8-719-210-33	DIODE EC10DS2	
C240	1-124-443-00	ELECT 100uF	20% 10V	D106	8-719-210-33	DIODE EC10DS2	
C241	1-124-443-00	ELECT 100uF	20% 10V	D107	8-719-210-33	DIODE EC10DS2	
C242	1-163-143-00	CERAMIC CHIP 0.0012uF	5% 50V	D108	8-719-210-33	DIODE EC10DS2	
C243	1-163-143-00	CERAMIC CHIP 0.0012uF	5% 50V	D109	8-719-021-97	DIODE UZM11X	
C248	1-124-443-00	ELECT 100uF	20% 10V	D110	8-719-210-33	DIODE EC10DS2	
C249	1-124-604-00	ELECT 330uF	20% 10V	D111	8-719-016-06	DIODE UZP-30BB	
C250	1-164-346-11	CERAMIC CHIP 1uF	16V	D112	8-719-015-02	DIODE UZP-8.2BB	
C253	1-126-176-11	ELECT 220uF	20% 10V	D113	8-719-014-42	DIODE UZP-4.3BA	
C254	1-124-902-00	ELECT 0.47uF	20% 50V	D114	8-719-800-76	DIODE 1SS226	
C255	1-126-101-11	ELECT 100uF	20% 16V	D115	8-719-800-76	DIODE 1SS226	
C256	1-124-925-11	ELECT 2.2uF	20% 100V	D116	8-719-990-39	DIODE DCB010	
C257	1-124-925-11	ELECT 2.2uF	20% 100V	D117	8-719-990-39	DIODE DCB010	
C258	1-124-915-11	ELECT 10uF	20% 63V	D118	8-719-210-33	DIODE EC10DS2	
C259	1-124-915-11	ELECT 10uF	20% 63V	D205	8-719-990-39	DIODE DCB010	
C260	1-124-915-11	ELECT 10uF	20% 63V	D206	8-719-210-33	DIODE EC10DS2	
C261	1-124-915-11	ELECT 10uF	20% 63V	D207	8-719-210-33	DIODE EC10DS2	
C262	1-124-915-11	ELECT 10uF	20% 63V	< IC >			
C263	1-124-915-11	ELECT 10uF	20% 63V	IC101	8-759-636-24	IC M5290FP	
C270	1-124-126-00	ELECT 47uF	20% 10V	IC102	8-759-605-00	IC M5F78M07L	
C271	1-124-604-00	ELECT 330uF	20% 10V	IC103	8-759-158-62	IC TA78057S	
C272	1-163-038-00	CERAMIC CHIP 0.1uF	25V	IC104	8-759-245-79	IC TA79005S	
C273	1-164-232-11	CERAMIC CHIP 0.01uF	50V	IC105	8-759-009-06	IC MC14052BF	
C274	1-163-038-00	CERAMIC CHIP 0.1uF	25V	IC106	8-749-921-12	IC GP1F32T (DIGITAL OPTICAL OUT)	
				IC201	8-759-163-37	IC UPD75516GF-461-3B9	
				IC202	8-752-352-93	IC CXD2500BQ	
				IC203	8-759-098-27	IC MSM6538-01GS-VKR1	
				IC204	8-759-155-52	IC PCM-67U-B	

MAIN

Ref. No.	Part No.	Description	Remark
IC205	8-759-636-55 IC	M5218AFP	
IC207	8-759-512-81 IC	LH5160N-10L	
IC208	8-759-009-21 IC	MC14093BF	
IC209	8-759-501-73 IC	BA6418N	
IC210	8-759-501-73 IC	BA6418N	
IC211	8-759-501-73 IC	BA6418N	
< JUMPER RESISTOR >			
JW102	1-216-295-00 METAL CHIP	0 5% 1/10W	
< COIL >			
L201	1-408-777-00 INDUCTOR CHIP	10uH	
L202	1-408-777-00 INDUCTOR CHIP	10uH	
L203	1-408-777-00 INDUCTOR CHIP	10uH	
< TRANSISTOR >			
Q101	8-729-209-15 TRANSISTOR	2SD2012	
Q103	8-729-602-21 TRANSISTOR	2SC4154-F	
Q104	8-729-018-59 TRANSISTOR	2SB1375-LC	
Q105	8-729-106-68 TRANSISTOR	2SD1615A-GP	
Q106	8-729-141-83 TRANSISTOR	2SB1094-LK	
Q107	8-729-805-41 TRANSISTOR	2SC3398	
Q108	8-729-018-59 TRANSISTOR	2SB1375-LC	
Q109	8-729-602-21 TRANSISTOR	2SC4154-F	
Q110	8-729-018-59 TRANSISTOR	2SB1375-LC	
Q111	8-729-602-36 TRANSISTOR	2SA1602-F	
Q112	8-729-805-41 TRANSISTOR	2SC3398	
< RESISTOR >			
R101	1-216-065-00 METAL CHIP	4.7K 5% 1/10W	
R102	1-216-065-00 METAL CHIP	4.7K 5% 1/10W	
R103	1-216-057-91 METAL GLAZE	2.2K 5% 1/10W	
R110	1-216-001-00 METAL CHIP	10 5% 1/10W	
△R111	1-217-637-00 FUSIBLE	1 5% 1/4W F	
R112	1-216-041-00 METAL CHIP	470 5% 1/10W	
R113	1-216-041-00 METAL CHIP	470 5% 1/10W	
R114	1-216-042-00 METAL CHIP	510 5% 1/10W	
R115	1-216-037-00 METAL CHIP	330 5% 1/10W	
R116	1-216-037-00 METAL CHIP	330 5% 1/10W	
R117	1-216-039-00 METAL CHIP	390 5% 1/10W	
R118	1-216-039-00 METAL CHIP	390 5% 1/10W	
R120	1-247-757-11 CARBON	2.7K 5% 1/2W	
R122	1-216-073-00 METAL CHIP	10K 5% 1/10W	
R123	1-216-073-00 METAL CHIP	10K 5% 1/10W	
R124	1-216-073-00 METAL CHIP	10K 5% 1/10W	
R125	1-216-049-00 METAL CHIP	1K 5% 1/10W	
R126	1-216-073-00 METAL CHIP	10K 5% 1/10W	
R127	1-216-073-00 METAL CHIP	10K 5% 1/10W	
R128	1-216-073-00 METAL CHIP	10K 5% 1/10W	

Ref. No.	Part No.	Description	Remark
R129	1-216-049-00 METAL CHIP	1K 5% 1/10W	
R130	1-216-049-00 METAL CHIP	1K 5% 1/10W	
R131	1-216-073-00 METAL CHIP	10K 5% 1/10W	
R132	1-216-073-00 METAL CHIP	10K 5% 1/10W	
R133	1-216-025-00 METAL CHIP	100 5% 1/10W	
R134	1-216-025-00 METAL CHIP	100 5% 1/10W	
R135	1-216-073-00 METAL CHIP	10K 5% 1/10W	
R136	1-216-073-00 METAL CHIP	10K 5% 1/10W	
R137	1-216-025-00 METAL CHIP	100 5% 1/10W	
R140	1-216-049-00 METAL CHIP	1K 5% 1/10W	
R141	1-216-049-00 METAL CHIP	1K 5% 1/10W	
R142	1-247-757-11 CARBON	2.7K 5% 1/2W	
△R143	1-217-640-91 FUSIBLE	3.3 5% 1/4W F	
R147	1-216-049-00 METAL CHIP	100 5% 1/10W	
R202	1-216-061-00 METAL CHIP	3.3K 5% 1/10W	
R203	1-216-061-00 METAL CHIP	3.3K 5% 1/10W	
R204	1-216-061-00 METAL CHIP	3.3K 5% 1/10W	
R205	1-216-061-00 METAL CHIP	3.3K 5% 1/10W	
R206	1-216-073-00 METAL CHIP	10K 5% 1/10W	
R207	1-216-073-00 METAL CHIP	10K 5% 1/10W	
R208	1-216-073-00 METAL CHIP	10K 5% 1/10W	
R209	1-216-073-00 METAL CHIP	10K 5% 1/10W	
R210	1-216-073-00 METAL CHIP	10K 5% 1/10W	
R211	1-216-073-00 METAL CHIP	10K 5% 1/10W	
R212	1-216-073-00 METAL CHIP	10K 5% 1/10W	
R213	1-216-073-00 METAL CHIP	10K 5% 1/10W	
R214	1-216-073-00 METAL CHIP	10K 5% 1/10W	
R215	1-216-073-00 METAL CHIP	10K 5% 1/10W	
R216	1-216-073-00 METAL CHIP	10K 5% 1/10W	
R217	1-216-073-00 METAL CHIP	10K 5% 1/10W	
R218	1-216-073-00 METAL CHIP	10K 5% 1/10W	
R219	1-216-073-00 METAL CHIP	10K 5% 1/10W	
R220	1-216-073-00 METAL CHIP	10K 5% 1/10W	
R221	1-216-049-00 METAL CHIP	1K 5% 1/10W	
R222	1-216-073-00 METAL CHIP	10K 5% 1/10W	
R223	1-216-073-00 METAL CHIP	10K 5% 1/10W	
R224	1-216-073-00 METAL CHIP	10K 5% 1/10W	
R225	1-216-073-00 METAL CHIP	10K 5% 1/10W	
R226	1-216-073-00 METAL CHIP	10K 5% 1/10W	
R227	1-216-073-00 METAL CHIP	10K 5% 1/10W	
R228	1-216-073-00 METAL CHIP	10K 5% 1/10W	
R229	1-216-073-00 METAL CHIP	10K 5% 1/10W	
R230	1-216-073-00 METAL CHIP	10K 5% 1/10W	
R231	1-216-073-00 METAL CHIP	10K 5% 1/10W	
R232	1-216-073-00 METAL CHIP	10K 5% 1/10W	

The components identified by mark △ or dotted line with mark △ are critical for safety.
Replace only with part number specified.

Les composants identifiés par une marque △ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

MAIN

MICROPHONE

Ref.No.	Part No.	Description	Remark
R233	1-216-073-00	METAL CHIP 10K 5% 1/10W	
R234	1-216-073-00	METAL CHIP 10K 5% 1/10W	
R235	1-216-073-00	METAL CHIP 10K 5% 1/10W	
R236	1-216-073-00	METAL CHIP 10K 5% 1/10W	
R237	1-216-073-00	METAL CHIP 10K 5% 1/10W	
R238	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R239	1-216-061-00	METAL CHIP 3.3K 5% 1/10W	
R240	1-216-061-00	METAL CHIP 3.3K 5% 1/10W	
R241	1-216-073-00	METAL CHIP 10K 5% 1/10W	
R242	1-216-073-00	METAL CHIP 10K 5% 1/10W	
R243	1-216-097-00	METAL CHIP 100K 5% 1/10W	
R244	1-216-041-00	METAL CHIP 470 5% 1/10W	
R245	1-216-041-00	METAL CHIP 470 5% 1/10W	
R246	1-216-041-00	METAL CHIP 470 5% 1/10W	
R247	1-216-041-00	METAL CHIP 470 5% 1/10W	
R248	1-216-033-00	METAL CHIP 220 5% 1/10W	
R249	1-216-041-00	METAL CHIP 470 5% 1/10W	
R250	1-216-041-00	METAL CHIP 470 5% 1/10W	
R251	1-216-041-00	METAL CHIP 470 5% 1/10W	
R252	1-216-041-00	METAL CHIP 470 5% 1/10W	
R253	1-216-041-00	METAL CHIP 470 5% 1/10W	
R254	1-216-045-00	METAL CHIP 680 5% 1/10W	
R255	1-216-045-00	METAL CHIP 680 5% 1/10W	
R256	1-216-057-91	METAL GLAZE 2.2K 5% 1/10W	
R257	1-216-057-91	METAL GLAZE 2.2K 5% 1/10W	
R262	1-216-025-00	METAL CHIP 100 5% 1/10W	
R263	1-216-025-00	METAL CHIP 100 5% 1/10W	
R264	1-216-031-00	METAL CHIP 180 5% 1/10W	
R265	1-216-031-00	METAL CHIP 180 5% 1/10W	
△R266	1-249-397-11	CARBON 22 5% 1/4W F	
△R267	1-249-397-11	CARBON 22 5% 1/4W F	
R268	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R269	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R270	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R271	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R272	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R273	1-216-025-00	METAL CHIP 100 5% 1/10W	
R276	1-216-025-00	METAL CHIP 100 5% 1/10W	
R277	1-216-025-00	METAL CHIP 100 5% 1/10W	
R278	1-216-089-91	METAL GLAZE 47K 5% 1/10W	
R279	1-216-089-91	METAL GLAZE 47K 5% 1/10W	

< TRANSFORMER >

△T101 1-423-771-11 TRANSFORMER, POWER

< TEST PIN >

* TP201 1-695-630-11 PIN, CONNECTOR 6P

Ref.No.	Part No.	Description	Remark
---------	----------	-------------	--------

< VIBRATOR >

X201 1-577-359-21 VIBRATOR, CERAMIC (4.19MHz)
X202 1-579-280-11 VIBRATOR, CRYSTAL (16MHz)

* 1-649-225-11 MICROPHONE BOARD

(C70:AEP, UK, E, AUS, G, IT, EA, SP, JE)

< CAPACITOR >

C501 1-124-257-00 ELECT 2.2uF 20% 50V
C502 1-163-141-00 CERAMIC CHIP 0.001uF 5% 50V
C503 1-163-121-00 CERAMIC CHIP 150PF 5% 50V
C504 1-163-125-00 CERAMIC CHIP 220PF 5% 50V
C505 1-124-464-11 ELECT 0.22uF 20% 50V

C506 1-126-157-11 ELECT 10uF 20% 16V
C507 1-124-907-11 ELECT 10uF 20% 50V
C508 1-164-004-11 CERAMIC CHIP 0.1uF 10% 25V
C555 1-124-464-11 ELECT 0.22uF 20% 50V
C556 1-126-157-11 ELECT 10uF 20% 16V

< IC >

IC501 8-759-603-13 IC M5218FP

< JACK >

J501 1-562-837-21 JACK (MIX MIC)

< RESISTOR >

R501 1-216-073-00 METAL CHIP 10K 5% 1/10W
R502 1-216-049-00 METAL CHIP 1K 5% 1/10W
R503 1-216-097-00 METAL CHIP 100K 5% 1/10W
R504 1-216-049-00 METAL CHIP 1K 5% 1/10W
R505 1-216-091-00 METAL CHIP 56K 5% 1/10W

R506 1-216-033-00 METAL CHIP 220 5% 1/10W
R507 1-216-073-00 METAL CHIP 10K 5% 1/10W
R508 1-216-091-00 METAL CHIP 56K 5% 1/10W
R509 1-216-097-00 METAL CHIP 100K 5% 1/10W
R510 1-216-033-00 METAL CHIP 220 5% 1/10W

R556 1-216-033-00 METAL CHIP 220 5% 1/10W

< VARIABLE RESISTOR >

RV501 1-223-434-11 RES, VAR, CARBON 50K (MIC LEVEL)

The components identified by mark △ or dotted line with mark △ are critical for safety.
Replace only with part number specified.

Les composants identifiés par une marque △ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

PANEL

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
*	A-4365-203-A	PANEL BOARD, COMPLETE (C70:US, CND/C90) *****		C701	1-126-177-11	ELECT 100uF 20%	10V
*	A-4365-204-A	PANEL BOARD, COMPLETE (C70:AEP, UK) *****		C702	1-165-319-11	CERAMIC CHIP 0.1uF	50V
*	A-4365-205-A	PANEL BOARD, COMPLETE ***** (C70:E, AUS, EA, SP, JE)		C706	1-163-234-00	CERAMIC CHIP 20PF 5%	50V
*	A-4365-206-A	PANEL BOARD, COMPLETE (C70:IT) *****		C707	1-163-234-00	CERAMIC CHIP 20PF 5%	50V
*	A-4365-210-A	PANEL BOARD, COMPLETE (C70:G) *****		C710	1-164-004-11	CERAMIC CHIP 0.1uF 10%	25V
*	4-921-941-01	CUSHION (FL)		C711	1-126-157-11	ELECT 10uF 20%	16V
*	4-954-701-01	HOLDER (FL TUBE)		C712	1-126-154-11	ELECT 47uF 20%	6.3V
*	4-959-227-01	HOLDER, LED		C713	1-136-173-00	FILM 0.47uF 5%	50V
*	4-959-581-01	COVER (SENSOR)		C714	1-136-173-00	FILM 0.47uF 5%	50V
*	4-960-269-01	HOLDER (FL)		C715	1-136-173-00	FILM 0.47uF 5%	50V
< CAPACITOR >				C717	1-163-251-11	CERAMIC CHIP 100PF 5%	50V
C603	1-164-695-11	CERAMIC CHIP 0.0022uF 5%	50V	C719	1-164-232-11	CERAMIC CHIP 0.01uF	50V
C604	1-165-319-11	CERAMIC CHIP 0.1uF	50V	C720	1-126-157-11	ELECT 10uF 20%	16V
C606	1-163-083-00	CERAMIC CHIP 1PF	50V	C721	1-165-319-11	CERAMIC CHIP 0.1uF	50V
C607	1-163-117-00	CERAMIC CHIP 100PF 5%	50V	C722	1-126-157-11	ELECT 10uF 20%	16V
C608	1-163-117-00	CERAMIC CHIP 100PF 5%	50V	C723	1-165-319-11	CERAMIC CHIP 0.1uF	50V
C609	1-163-117-00	CERAMIC CHIP 100PF 5%	50V	C725	1-163-141-00	CERAMIC CHIP 0.001uF 5%	50V
C610	1-163-117-00	CERAMIC CHIP 100PF 5%	50V	C726	1-164-004-11	CERAMIC CHIP 0.1uF 10%	25V
C611	1-163-117-00	CERAMIC CHIP 100PF 5%	50V	C727	1-164-004-11	CERAMIC CHIP 0.1uF 10%	25V
C612	1-163-117-00	CERAMIC CHIP 100PF 5%	50V	C728	1-164-004-11	CERAMIC CHIP 0.1uF 10%	25V
C613	1-163-117-00	CERAMIC CHIP 100PF 5%	50V	C729	1-164-004-11	CERAMIC CHIP 0.1uF 10%	25V
C614	1-163-117-00	CERAMIC CHIP 100PF 5%	50V	< CERAMIC FILTER >			
C615	1-163-117-00	CERAMIC CHIP 100PF 5%	50V	CF701	1-579-125-11	VIBRATOR, CERAMIC (8MHz)	
C616	1-163-117-00	CERAMIC CHIP 100PF 5%	50V	< CONNECTOR >			
C617	1-163-117-00	CERAMIC CHIP 100PF 5%	50V	* CN601	1-568-864-11	SOCKET, CONNECTOR 21P	
C618	1-163-117-00	CERAMIC CHIP 100PF 5%	50V	* CN602	1-568-856-11	SOCKET, CONNECTOR 13P	
C619	1-163-117-00	CERAMIC CHIP 100PF 5%	50V	< DIODE >			
C620	1-163-117-00	CERAMIC CHIP 100PF 5%	50V	D601	8-719-990-39	DIODE DCB010	
C621	1-163-117-00	CERAMIC CHIP 100PF 5%	50V	D620	8-719-045-13	DIODE SEL2910A-TP6 (DISC 4)	
C622	1-164-004-11	CERAMIC CHIP 0.1uF 10%	25V	D621	8-719-045-13	DIODE SEL2910A-TP6 (DISC 3)	
C623	1-164-232-11	CERAMIC CHIP 0.01uF	50V	D622	8-719-045-13	DIODE SEL2910A-TP6 (DISC 2)	
C624	1-124-443-00	ELECT 100uF 20%	10V	D623	8-719-045-13	DIODE SEL2910A-TP6 (DISC 1)	
C625	1-126-177-11	ELECT 100uF 20%	10V	D624	8-719-045-13	DIODE SEL2910A-TP6 (DISC 5)	
C626	1-163-117-00	CERAMIC CHIP 100PF 5%	50V	D625	8-719-041-92	DIODE SEL2410E-C-TP6 (DISC 4)	
C627	1-163-117-00	CERAMIC CHIP 100PF 5%	50V	D626	8-719-041-92	DIODE SEL2410E-C-TP6 (DISC 3)	
C628	1-126-948-11	ELECT 100uF 20%	50V	D627	8-719-041-92	DIODE SEL2410E-C-TP6 (DISC 2)	
C630	1-164-004-11	CERAMIC CHIP 0.1uF 10%	25V	D628	8-719-041-92	DIODE SEL2410E-C-TP6 (DISC 1)	
C631	1-126-157-11	ELECT 10uF 20%	16V	D629	8-719-041-92	DIODE SEL2410E-C-TP6 (DISC 5)	
C632	1-165-319-11	CERAMIC CHIP 0.1uF	50V	D630	8-719-029-95	DIODE TLN117	
C633	1-164-346-11	CERAMIC CHIP 1uF	16V	D701	8-719-990-39	DIODE DCB010	
C634	1-164-346-11	CERAMIC CHIP 1uF	16V	D702	8-719-990-39	DIODE DCB010	
				D703	8-719-990-39	DIODE DCB010	
				D704	8-719-990-39	DIODE DCB010	
				D706	8-719-990-39	DIODE DCB010 (C70:US, CND, IT/C90)	
				D707	8-719-990-39	DIODE DCB010 (C70:AEP, UK, IT)	
				D708	8-719-990-39	DIODE DCB010 (C70:E, AUS, G, EA, SP, JE)	
				D710	8-719-038-63	DIODE SEL5220S-TH8C (PRESET)	

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
D711	8-719-038-63	DIODE SEL5220S-TH8C (TUNING)		R614	1-216-073-00	METAL CHIP 10K 5%	1/10W
D712	8-719-990-39	DIODE DCB010		R615	1-216-061-00	METAL CHIP 3.3K 5%	1/10W
D716	8-719-990-39	DIODE DCB010		R617	1-216-061-00	METAL CHIP 3.3K 5%	1/10W
D717	8-719-990-39	DIODE DCB010		R618	1-216-061-00	METAL CHIP 3.3K 5%	1/10W
D718	8-719-990-39	DIODE DCB010		R619	1-216-061-00	METAL CHIP 3.3K 5%	1/10W
< FLUORESCENT INDICATOR >				R620	1-216-033-00	METAL CHIP 220 5%	1/10W
FL601	1-519-738-11	INDICATOR TUBE, FLUORESCENT		R621	1-216-033-00	METAL CHIP 220 5%	1/10W
FL701	1-517-215-11	INDICATOR TUBE, FLUORESCENT		R622	1-216-033-00	METAL CHIP 220 5%	1/10W
< IC >				R623	1-216-033-00	METAL CHIP 220 5%	1/10W
IC601	8-759-184-09	IC 75518GF-127-3B9		R624	1-216-033-00	METAL CHIP 220 5%	1/10W
IC602	8-759-077-16	IC M66004M4FP		R625	1-216-035-00	METAL CHIP 270 5%	1/10W
IC603	8-759-165-81	IC PST600D-T		R626	1-216-035-00	METAL CHIP 270 5%	1/10W
IC701	8-759-183-99	IC TMP87CC70F-6129		R627	1-216-035-00	METAL CHIP 270 5%	1/10W
IC702	8-759-504-12	IC X24C01S		R628	1-216-035-00	METAL CHIP 270 5%	1/10W
IC703	8-759-165-81	IC PST600D-T		R629	1-216-035-00	METAL CHIP 270 5%	1/10W
IC704	8-759-165-84	IC PST600G-T		R632	1-216-065-00	METAL CHIP 4.7K 5%	1/10W
IC705	8-749-923-80	IC GPIU90XB		R633	1-216-073-00	METAL CHIP 10K 5%	1/10W
< COIL >				R635	1-216-049-00	METAL CHIP 1K 5%	1/10W
L601	1-410-521-11	INDUCTOR 100uH		R636	1-216-049-00	METAL CHIP 1K 5%	1/10W
L701	1-410-521-11	INDUCTOR 100uH		R637	1-216-079-00	METAL CHIP 18K 5%	1/10W
L702	1-410-521-11	INDUCTOR 100uH		R638	1-216-109-91	METAL GLAZE 330K 5%	1/10W
L703	1-410-521-11	INDUCTOR 100uH		R651	1-216-041-00	METAL CHIP 470 5%	1/10W
< TRANSISTOR >				R652	1-216-041-00	METAL CHIP 470 5%	1/10W
Q601	8-729-602-21	TRANSISTOR 2SC4154-F		R653	1-216-081-00	METAL CHIP 22K 5%	1/10W
Q604	8-729-018-23	TRANSISTOR TPS626		R654	1-216-041-00	METAL CHIP 470 5%	1/10W
Q612	8-729-602-21	TRANSISTOR 2SC4154-F		R655	1-216-045-00	METAL CHIP 680 5%	1/10W
Q613	8-729-602-21	TRANSISTOR 2SC4154-F		R656	1-216-045-00	METAL CHIP 680 5%	1/10W
Q701	8-729-805-41	TRANSISTOR 2SC3398		R657	1-216-037-00	METAL CHIP 330 5%	1/10W
Q702	8-729-805-41	TRANSISTOR 2SC3398		R658	1-216-045-00	METAL CHIP 680 5%	1/10W
Q706	8-729-805-41	TRANSISTOR 2SC3398		R659	1-216-049-00	METAL CHIP 1K 5%	1/10W
Q707	8-729-602-21	TRANSISTOR 2SC4154-F		R660	1-216-049-00	METAL CHIP 1K 5%	1/10W
< RESISTOR >				R661	1-216-033-00	METAL CHIP 220 5%	1/10W
R601	1-216-061-00	METAL CHIP 3.3K 5%	1/10W	R662	1-216-049-00	METAL CHIP 1K 5%	1/10W
R602	1-216-061-00	METAL CHIP 3.3K 5%	1/10W	R663	1-216-053-00	METAL CHIP 1.5K 5%	1/10W
R603	1-216-061-00	METAL CHIP 3.3K 5%	1/10W	R664	1-216-053-00	METAL CHIP 1.5K 5%	1/10W
R604	1-216-061-00	METAL CHIP 3.3K 5%	1/10W	R666	1-216-053-00	METAL CHIP 1.5K 5%	1/10W
R605	1-216-073-00	METAL CHIP 10K 5%	1/10W	R667	1-216-057-91	METAL GLAZE 2.2K 5%	1/10W
R606	1-216-073-00	METAL CHIP 10K 5%	1/10W	R668	1-216-057-91	METAL GLAZE 2.2K 5%	1/10W
R607	1-216-073-00	METAL CHIP 10K 5%	1/10W	R670	1-216-057-91	METAL GLAZE 2.2K 5%	1/10W
R608	1-216-073-00	METAL CHIP 10K 5%	1/10W	R671	1-216-065-00	METAL CHIP 4.7K 5%	1/10W
R609	1-216-073-00	METAL CHIP 10K 5%	1/10W	R672	1-216-065-00	METAL CHIP 4.7K 5%	1/10W
R610	1-216-073-00	METAL CHIP 10K 5%	1/10W	R674	1-216-065-00	METAL CHIP 4.7K 5%	1/10W
R611	1-216-073-00	METAL CHIP 10K 5%	1/10W	R675	1-216-075-00	METAL CHIP 12K 5%	1/10W
R612	1-216-089-91	METAL GLAZE 47K 5%	1/10W	R676	1-216-075-00	METAL CHIP 12K 5%	1/10W
R613	1-216-073-00	METAL CHIP 10K 5%	1/10W	R678	1-216-075-00	METAL CHIP 12K 5%	1/10W
				R701	1-216-049-00	METAL CHIP 1K 5%	1/10W
				R702	1-216-049-00	METAL CHIP 1K 5%	1/10W
				R703	1-216-049-00	METAL CHIP 1K 5%	1/10W
				R704	1-216-049-00	METAL CHIP 1K 5%	1/10W
				R705	1-216-049-00	METAL CHIP 1K 5%	1/10W

PANEL

TCB011

Ref.No.	Part No.	Description	Remark
R706	1-216-061-00	METAL CHIP 3.3K 5% 1/10W	
R707	1-216-061-00	METAL CHIP 3.3K 5% 1/10W	
R708	1-216-057-91	METAL GLAZE 2.2K 5% 1/10W	
R709	1-216-061-00	METAL CHIP 3.3K 5% 1/10W	
R710	1-216-073-00	METAL CHIP 10K 5% 1/10W	
R711	1-216-073-00	METAL CHIP 10K 5% 1/10W	
R712	1-216-037-00	METAL CHIP 330 5% 1/10W	
R716	1-216-073-00	METAL CHIP 10K 5% 1/10W	
R717	1-216-065-00	METAL CHIP 4.7K 5% 1/10W	
R718	1-216-073-00	METAL CHIP 10K 5% 1/10W	
R719	1-216-073-00	METAL CHIP 10K 5% 1/10W	
R720	1-216-073-00	METAL CHIP 10K 5% 1/10W	
R721	1-216-073-00	METAL CHIP 10K 5% 1/10W	
R723	1-216-061-00	METAL CHIP 3.3K 5% 1/10W	
R724	1-216-049-00	METAL CHIP 10K 5% 1/10W	
R725	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R726	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R727	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R728	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R729	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R730	1-216-049-00	METAL CHIP 1K 5% 1/10W	
R736	1-216-073-00	METAL CHIP 10K 5% 1/10W	
R739	1-216-025-00	METAL CHIP 100 5% 1/10W	
R740	1-216-105-00	METAL CHIP 220K 5% 1/10W	
R741	1-216-109-91	METAL GLAZE 330K 5% 1/10W	
< SWITCH >			
S601	1-554-303-21	SWITCH, TACTILE (▷▷▷)	
S602	1-554-303-21	SWITCH, TACTILE (◁◁◁)	
S603	1-554-303-21	SWITCH, TACTILE (■)	
S604	1-554-303-21	SWITCH, TACTILE (▷)	
S605	1-554-303-21	SWITCH, TACTILE (DISC 1)	
S606	1-554-303-21	SWITCH, TACTILE (OPEN/CLOSE △ (1))	
S608	1-554-303-21	SWITCH, TACTILE (■)	
S609	1-554-303-21	SWITCH, TACTILE (DISC 2)	
S610	1-554-303-21	SWITCH, TACTILE (△ (2))	
S612	1-554-303-21	SWITCH, TACTILE (CONTINUE)	
S613	1-554-303-21	SWITCH, TACTILE (DISC 3)	
S614	1-554-303-21	SWITCH, TACTILE (△ (3))	
S616	1-554-303-21	SWITCH, TACTILE (SHUFFLE)	
S617	1-554-303-21	SWITCH, TACTILE (DISC 4)	
S618	1-554-303-21	SWITCH, TACTILE (△ (4))	
S620	1-554-303-21	SWITCH, TACTILE (PROGRAM)	
S621	1-554-303-21	SWITCH, TACTILE (DISC 5)	
S622	1-554-303-21	SWITCH, TACTILE (△ (5) DISC CHECK)	
S624	1-554-303-21	SWITCH, TACTILE (REPEAT)	
S625	1-554-303-21	SWITCH, TACTILE (CHARACTER ▷)	
S626	1-554-303-21	SWITCH, TACTILE (CHARACTER ◁)	
S628	1-554-303-21	SWITCH, TACTILE (CURSOR)	
S629	1-554-303-21	SWITCH, TACTILE (MEMO INPUT)	

Ref.No.	Part No.	Description	Remark
S630	1-554-303-21	SWITCH, TACTILE (ERASE)	
S631	1-554-303-21	SWITCH, TACTILE (TIME/MEMO)	
S632	1-554-303-21	SWITCH, TACTILE (S.F. FILE)	
S701	1-554-303-21	SWITCH, TACTILE (WAKE UP TIMER 1)	
S702	1-554-303-21	SWITCH, TACTILE (WAKE UP TIMER 2)	
S703	1-554-303-21	SWITCH, TACTILE (TUNER REC)	
S705	1-554-303-21	SWITCH, TACTILE (MEMORY/NEXT)	
S706	1-554-303-21	SWITCH, TACTILE (MODE)	
S707	1-554-303-21	SWITCH, TACTILE (STEREO/MONO)	
S708	1-554-303-21	SWITCH, TACTILE (BAND)	
S709	1-554-303-21	SWITCH, TACTILE (-)	
S710	1-554-303-21	SWITCH, TACTILE (+)	
< VIBRATOR >			
X601	1-577-359-21	VIBRATOR, CERAMIC (4.19MHz)	
X701	1-567-098-00	OSCILLATOR, CRYSTAL (32kHz)	

*	A-4303-342-A	TCB011 BOARD, COMPLETE (C70:US, CND/C90)	

*	A-4303-343-A	TCB011 BOARD, COMPLETE (C70:AEP, UK)	

*	A-4303-344-A	TCB011 BOARD, COMPLETE (C70:G, IT)	

*	A-4303-345-A	TCB011 BOARD, COMPLETE	

(C70:E, EA, AUS, JE, SP)			
< CAPACITOR >			
C1	1-124-120-11	ELECT 220uF 20% 25V	
C2	1-164-232-11	CERAMIC CHIP 0.01uF 50V	
C3	1-163-009-11	CERAMIC CHIP 0.001uF 10% 50V	
C4	1-163-038-00	CERAMIC CHIP 0.1uF 25V	
(C70:G, IT)			
C5	1-164-232-11	CERAMIC CHIP 0.01uF 50V	
C6	1-163-038-00	CERAMIC CHIP 0.1uF 25V	
(C70:AEP, UK, G, IT)			
C7	1-163-038-00	CERAMIC CHIP 0.1uF 25V	
(C70:G, IT)			
C8	1-164-232-11	CERAMIC CHIP 0.01uF 50V	
(C70:AEP, UK, G, IT)			
C9	1-163-012-00	CERAMIC CHIP 0.0018uF 10% 50V	
(C70:AEP, UK, G, IT)			
C10	1-163-011-11	CERAMIC CHIP 0.0015uF 10% 50V	
(C70:AEP, UK, G, IT)			
C12	1-164-343-91	CERAMIC CHIP 0.056uF 10% 50V	
(C70:E, AUS, EA, SP, JE)			
C13	1-164-232-11	CERAMIC CHIP 0.01uF 50V	
(C70:E, AUS, EA, SP, JE)			

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
C14	1-163-577-91	CERAMIC CHIP 5PF 0.25PF 50V (C70:E, AUS, EA, SP, JE)		C73	1-164-505-11	CERAMIC CHIP 2.2uF 16V	
C21	1-163-103-00	CERAMIC CHIP 27PF 5% 50V		C74	1-164-232-11	CERAMIC CHIP 0.01uF 50V	
C22	1-163-103-00	CERAMIC CHIP 27PF 5% 50V		C75	1-126-157-11	ELECT 10uF 20% 16V	
C23	1-164-232-11	CERAMIC CHIP 0.01uF 50V		C76	1-126-101-11	ELECT 100uF 20% 16V	
C24	1-164-232-11	CERAMIC CHIP 0.01uF 50V		C79	1-126-157-11	ELECT 10uF 20% 16V	
C25	1-164-232-11	CERAMIC CHIP 0.01uF 50V		C80	1-124-472-11	ELECT 470uF 20% 10V	
C26	1-164-346-11	CERAMIC CHIP 1uF 16V		C81	1-164-232-11	CERAMIC CHIP 0.01uF 50V	
C27	1-164-505-11	CERAMIC CHIP 2.2uF 16V		C82	1-164-232-11	CERAMIC CHIP 0.01uF 50V	
C29	1-164-232-11	CERAMIC CHIP 0.01uF 50V		C83	1-164-232-11	CERAMIC CHIP 0.01uF 50V (C70:G, IT)	
C31	1-164-505-11	CERAMIC CHIP 2.2uF 16V		< CERAMIC FILTER >			
C32	1-164-232-11	CERAMIC CHIP 0.01uF 50V		CF1	1-527-968-11	FILTER, CERAMIC (10.7MHz) (C70:E, AUS, EA, SP, JE)	
C33	1-163-038-00	CERAMIC CHIP 0.1uF 25V		CF1	1-567-389-11	FILTER, CERAMIC (10.7MHz) (C70:AEP, UK, G, IT)	
C34	1-164-005-11	CERAMIC CHIP 0.47uF 25V (C70:AEP, UK, G, IT)		CF1	1-579-675-11	FILTER, CERAMIC (10.7MHz) (C70:US, CND/C90)	
C35	1-163-033-00	CERAMIC CHIP 0.022uF 50V (C70:AEP, UK, G, IT)		CF2	1-567-389-11	FILTER, CERAMIC (10.7MHz) (C70:G, IT)	
C36	1-163-033-00	CERAMIC CHIP 0.022uF 50V (C70:AEP, UK, G, IT)		CF51	1-579-675-11	FILTER, CERAMIC (10.7MHz) (C70:US, CND/C90)	
C51	1-164-232-11	CERAMIC CHIP 0.01uF 50V		CF51	1-567-389-11	FILTER, CERAMIC (10.7MHz) (C70:AEP, UK, E, AUS, G, IT, EA, SP, JE)	
C52	1-123-613-91	ELECT 3.3uF 35V (C70:US, CND, E, AUS, EA, SP, JE/C90)		< CONNECTOR >			
C52	1-164-505-11	CERAMIC CHIP 2.2uF 16V (C70:AEP, UK, G, IT)		CN1	1-573-105-11	CONNECTOR, PC BOARD (RECEPTACLE) 4P	
C53	1-164-232-11	CERAMIC CHIP 0.01uF 50V		CN2	1-573-105-11	CONNECTOR, PC BOARD (RECEPTACLE) 4P	
C54	1-164-232-11	CERAMIC CHIP 0.01uF 50V		CN3	1-573-105-11	CONNECTOR, PC BOARD (RECEPTACLE) 4P (C70:US, CND/C90)	
C55	1-163-105-00	CERAMIC CHIP 33PF 5% 50V (C70:US, CND, AEP, UK, E, AUS, EA, SP, JE/C90)		CN3	1-659-808-11	CONNECTOR, PC BOARD (RECEPTACLE) 8P (C70:AEP, UK, E, AUS, G, IT, EA, SP, JE)	
C55	1-163-135-00	CERAMIC CHIP 560PF 5% 50V (C70:G, IT)		CN4	1-573-105-11	CONNECTOR, PC BOARD (RECEPTACLE) 4P (C70:US, CND/C90)	
C56	1-163-117-00	CERAMIC CHIP 100PF 5% 50V (C70:G, IT)		CN5	1-573-105-11	CONNECTOR, PC BOARD (RECEPTACLE) 4P	
C57	1-164-346-11	CERAMIC CHIP 1uF 16V		< TRIMER >			
C58	1-164-346-11	CERAMIC CHIP 1uF 16V		CV1	1-141-265-31	TRIMER CAPACITOR (C70:E)	
C59	1-164-346-11	CERAMIC CHIP 1uF 16V		CV2	1-141-265-31	TRIMER CAPACITOR (C70:E)	
C60	1-163-038-00	CERAMIC CHIP 0.1uF 25V		< DIODE >			
C61	1-163-022-00	CERAMIC CHIP 0.012uF 10% 50V (C70:AEP, UK, E, AUS, G, IT, EA, SP, JE)		D1	8-719-975-10	DIODE KV1560NT (C70:E)	
C61	1-163-032-00	CERAMIC CHIP 0.015uF 50V (C70:US, CND/C90)		D21	8-719-422-46	DIODE MA8056	
C62	1-163-022-00	CERAMIC CHIP 0.012uF 10% 50V (C70:AEP, UK, E, AUS, G, IT, EA, SP, JE)		D51	8-719-016-74	DIODE 1SS352	
C62	1-163-032-00	CERAMIC CHIP 0.015uF 50V (C70:US, CND/C90)		< FRONTEND >			
C63	1-164-346-11	CERAMIC CHIP 1uF 16V		FE1	1-465-673-11	FRONTEND (FM 2 BAND) (FM) (C70:US, CND, AEP, UK, E, AUS, EA, SP, JE/C90)	
C64	1-164-346-11	CERAMIC CHIP 1uF 16V		FE1	1-463-957-11	FRONTEND (FM 4 BAND) (FM) (C70:G, IT)	
C65	1-164-346-11	CERAMIC CHIP 1uF 16V		FE2	1-239-030-11	ENCAPSULATED COMPONENT (MW) (C70:AEP, UK, G, IT)	
C66	1-164-346-11	CERAMIC CHIP 1uF 16V		FE2	1-239-031-11	ENCAPSULATED COMPONENT (AM) (C70:US, CND/C90)	
C69	1-164-232-11	CERAMIC CHIP 0.01uF 50V					
C70	1-164-232-11	CERAMIC CHIP 0.01uF 50V					
C71	1-164-232-11	CERAMIC CHIP 0.01uF 50V					
C72	1-124-120-11	ELECT 220uF 20% 25V					

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
FE2	1-239-032-11	ENCAPSULATED COMPONENT (MW) (C70:US, CND, E, AUS, EA, SP, JE/C90)		Q22	8-729-232-69	TRANSISTOR 2SK208GR3	
FE3	1-239-049-11	ENCAPSULATED COMPONENT (LW) (C70:AEP, UK, G, IT)		Q23	8-729-232-59	TRANSISTOR 2SC4666B	
		< FILTER >		Q24	8-729-232-69	TRANSISTOR 2SK208GR3 (C70:AEP, UK, G, IT)	
				Q25	8-729-232-59	TRANSISTOR 2SC4666B (C70:AEP, UK, G, IT)	
FL51	1-239-029-11	ENCAPSULATED COMPONENT (C70:G, IT)		Q51	8-729-602-21	TRANSISTOR 2SC4154-F	
		< IC >		Q52	8-729-602-21	TRANSISTOR 2SC4154-F	
IC21	8-759-821-43	1C LC7218M		Q53	8-729-810-28	TRANSISTOR 2SC4398	
IC51	8-759-823-68	IC LA1851NM				< RESISTOR >	
		< IFT >		R1	1-216-037-00	METAL CHIP 330 5% 1/10W	
IFT51	1-404-954-11	TRANSFORMER, DISCRIMINATOR (FM DET)		R2	1-216-037-00	METAL CHIP 330 5% 1/10W	
IFT52	1-404-713-11	TRANSFORMER, IF (MW/LW IF)		R3	1-216-109-00	METAL CHIP 330K 5% 1/10W	
		< JUMPER RESISTOR >		R4	1-216-037-00	METAL CHIP 330 5% 1/10W	
JW1	1-216-295-00	METAL CHIP 0 5% 1/10W		R5	1-216-109-00	METAL CHIP 330K 5% 1/10W (C70:G, IT)	
JW2	1-216-295-00	METAL CHIP 0 5% 1/10W (C70:US, CND, AEP, UK, E, AUS, EA, SP, JE/C90)		R6	1-216-037-00	METAL CHIP 330 5% 1/10W (C70:G, IT)	
JW3	1-216-295-00	METAL CHIP 0 5% 1/10W (C70:E, AUS, EA, SP, JE)		R7	1-216-025-00	METAL CHIP 100 5% 1/10W	
JW4	1-216-295-00	METAL CHIP 0 5% 1/10W (C70:US, CND, AEP, UK, G, IT/C90)		R8	1-216-037-00	METAL CHIP 330 5% 1/10W (C70:E, AUS, EA, SP, JE)	
JW5	1-216-295-00	METAL CHIP 0 5% 1/10W (C70:US, CND, AEP, UK, G, IT/C90)		R8	1-216-057-00	METAL CHIP 2.2K 5% 1/10W (C70:AEP, UK, G, IT)	
JW6	1-216-295-00	METAL CHIP 0 5% 1/10W (C70:US, CND/C90)		R9	1-216-089-00	METAL CHIP 47K 5% 1/10W	
JW7	1-216-295-00	METAL CHIP 0 5% 1/10W (C70:AEP, UK, G, IT)		R10	1-216-097-00	METAL CHIP 100K 5% 1/10W	
		< COIL >		R11	1-216-065-00	METAL CHIP 4.7K 5% 1/10W (C70:AEP, UK, G, IT)	
L1	1-408-793-21	INDUCTOR CHIP 220uH (C70:AEP, UK, G, IT)		R12	1-216-057-00	METAL CHIP 2.2K 5% 1/10W (C70:AEP, UK, G, IT)	
L51	1-408-798-00	INDUCTOR CHIP 1mH		R13	1-216-089-00	METAL CHIP 47K 5% 1/10W (C70:AEP, UK, G, IT)	
		< LPF >		R14	1-216-081-00	METAL CHIP 22K 5% 1/10W (C70:AEP, UK, G, IT)	
LPF51	1-235-221-00	FILTER, LOW PASS		R15	1-216-121-00	METAL CHIP 1M 5% 1/10W (C70:AEP, UK, G, IT)	
		< TRANSISTOR >		R16	1-216-073-00	METAL CHIP 10K 5% 1/10W (C70:E, AUS, EA, SP, JE)	
Q1	8-729-804-72	TRANSISTOR 2SC2814-F4		R16	1-216-089-00	METAL CHIP 47K 5% 1/10W (C70:AEP, UK)	
Q2	8-729-804-72	TRANSISTOR 2SC2814-F4 (C70:G, IT)		R17	1-216-121-00	METAL CHIP 1M 5% 1/10W (C70:E, AUS, EA, SP, JE)	
Q3	8-729-810-16	TRANSISTOR 2SA1678		R18	1-216-073-00	METAL CHIP 10K 5% 1/10W (C70:E, AUS, EA, SP, JE)	
Q4	8-729-602-36	TRANSISTOR 2SA1602 (C70:AEP, UK, E, AUS, G, IT, EA, SP, JE)		R21	1-216-049-00	METAL CHIP 1K 5% 1/10W	
Q5	8-729-602-36	TRANSISTOR 2SA1602 (C70:E, AUS, EA, SP, JE)		R22	1-216-049-00	METAL CHIP 1K 5% 1/10W	
Q5	8-729-810-28	TRANSISTOR 2SC4398 (C70:AEP, UK, G, IT)		R23	1-216-049-00	METAL CHIP 1K 5% 1/10W	
Q6	8-729-602-36	TRANSISTOR 2SA1602 (C70:AEP, UK, E, AUS, G, IT, EA, SP, JE)		R24	1-216-025-00	METAL CHIP 100 5% 1/10W	
Q7	8-729-810-28	TRANSISTOR 2SC4398 (C70:AEP, UK, G, IT)		R25	1-216-065-00	METAL CHIP 4.7K 5% 1/10W	
Q21	8-729-602-21	TRANSISTOR 2SC4154-F		R26	1-216-049-00	METAL CHIP 1K 5% 1/10W	
				R27	1-216-073-00	METAL CHIP 10K 5% 1/10W (C70:AEP, UK, E, AUS, G, IT, EA, SP, JE)	
				R28	1-216-073-00	METAL CHIP 10K 5% 1/10W	
				R29	1-216-025-00	METAL CHIP 100 5% 1/10W	
				R30	1-216-061-00	METAL CHIP 3.3K 5% 1/10W	

TCB011	TUNER
--------	-------

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
R31	1-216-043-00	METAL CHIP	560 5% 1/10W	R75	1-216-061-00	METAL CHIP 3.3K 5% 1/10W	(C70:AEP, UK, G, IT)
R32	1-216-049-00	METAL CHIP	1K 5% 1/10W	R79	1-216-049-00	METAL CHIP 1K 5% 1/10W	(C70:US, CND, AEP, UK, E, AUS, EA, SP, JE/C90)
R33	1-216-035-00	METAL CHIP	270 5% 1/10W	R79	1-216-055-00	METAL CHIP 1.8K 5% 1/10W	(C70:G, IT)
R34	1-216-065-00	METAL CHIP	4.7K 5% 1/10W			< VARIABLE RESISTOR >	
R35	1-216-057-00	METAL CHIP	2.2K 5% 1/10W	RV51	1-238-601-11	RES, ADJ, CARBON 22K	(MW/LW TUNED IND. LEVEL)
R36	1-216-065-00	METAL CHIP	4.7K 5% 1/10W	RV52	1-238-601-11	RES, ADJ, CARBON 22K	(FW TUNED IND. LEVEL)
R37	1-216-065-00	METAL CHIP	4.7K 5% 1/10W			< COIL >	
R38	1-216-025-00	METAL CHIP	100 5% 1/10W	T1	1-402-547-11	COIL (ANT FOR SW3)	(C70:E, AUS, EA, SP, JE)
R39	1-216-061-00	METAL CHIP	3.3K 5% 1/10W	T2	1-406-415-11	COIL (OSC FOR SW3)	(C70:E, AUS, EA, SP, JE)
R40	1-216-043-00	METAL CHIP	560 5% 1/10W			< TEST PIN >	
			(C70:AEP, UK, G, IT)	* TP51	1-564-336-00	PIN, CONNECTOR 2P	(C70:US, CND, AEP, UK, E, AUS, EA, SP, JE/C90)
R41	1-216-049-00	METAL CHIP	1K 5% 1/10W	* TP51	1-568-449-11	HOUSING, CONNECTOR (PC BOARD)	3P (C70:G, IT)
R42	1-216-035-00	METAL CHIP	270 5% 1/10W			< VIBRATOR >	
R43	1-216-081-00	METAL CHIP	22K 5% 1/10W	X21	1-577-126-11	VIBRATOR, CRYSTAL (7.2MHz)	
R44	1-216-057-00	METAL CHIP	2.2K 5% 1/10W	X51	1-577-075-11	OSCILLATOR, CERAMIC (456kHz)	
R45	1-216-065-00	METAL CHIP	4.7K 5% 1/10W			*****	
			(C70:AEP, UK, G, IT)	*	1-649-358-11	TUNER BOARD	*****
R46	1-216-065-00	METAL CHIP	4.7K 5% 1/10W				(C70:US, CND, E, AUS, EA, SP, JE/C90)
			(C70:AEP, UK, G, IT)	*	1-649-359-11	TUNER BOARD (C70:AEP, UK, G, IT)	*****
R47	1-216-025-00	METAL CHIP	100 5% 1/10W			< CONNECTOR >	
			(C70:US, CND, E, AUS, EA, SP, JE/C90)	* CN301	1-568-856-11	SOCKET, CONNECTOR 13P	
R51	1-216-049-00	METAL CHIP	1K 5% 1/10W	* CN302	1-691-007-11	CONNECTOR (PC BOARD) (PLUG) 4P	
R52	1-216-081-00	METAL CHIP	22K 5% 1/10W	* CN303	1-691-007-11	CONNECTOR (PC BOARD) (PLUG) 4P	
R53	1-216-085-00	METAL CHIP	33K 5% 1/10W	CN304	1-764-187-11	PIN, CONNECTOR	
R54	1-216-071-00	METAL CHIP	8.2K 5% 1/10W	* CN305	1-691-007-11	CONNECTOR (PC BOARD) (PLUG) 4P	
R55	1-216-075-00	METAL CHIP	12K 5% 1/10W	* CN307	1-569-504-11	PIN, CONNECTOR 9P	
			(C70:US, CND, AEP, UK, E, AUS, EA, SP, JE/C90)			< TERMINAL >	
R56	1-216-075-00	METAL CHIP	12K 5% 1/10W	* TM301	1-537-288-11	TERMINAL BOARD, ANTENNA (PAL)	(ANTENNA)
R57	1-216-073-00	METAL CHIP	10K 5% 1/10W				(C70:AEP, UK, G, IT)
R58	1-216-066-00	METAL CHIP	5.1K 5% 1/10W	TM301	1-537-466-11	TERMINAL BOARD (ANT)	(ANTENNA)
R59	1-216-065-00	METAL CHIP	4.7K 5% 1/10W				(C70:US, CND, E, AUS, EA, SP, JE/C90)
R60	1-216-065-00	METAL CHIP	4.7K 5% 1/10W			*****	
R61	1-216-115-00	METAL CHIP	560K 5% 1/10W				
R62	1-216-115-00	METAL CHIP	560K 5% 1/10W				
R63	1-216-049-00	METAL CHIP	1K 5% 1/10W				
R64	1-216-049-00	METAL CHIP	1K 5% 1/10W				
R65	1-216-073-00	METAL CHIP	10K 5% 1/10W				
R66	1-216-073-00	METAL CHIP	10K 5% 1/10W				
R67	1-216-057-00	METAL CHIP	2.2K 5% 1/10W				
R68	1-216-057-00	METAL CHIP	2.2K 5% 1/10W				
R69	1-216-025-00	METAL CHIP	100 5% 1/10W				
R70	1-216-025-00	METAL CHIP	100 5% 1/10W				
R71	1-216-089-00	METAL CHIP	47K 5% 1/10W				
R72	1-216-073-00	METAL CHIP	10K 5% 1/10W				
R73	1-216-073-00	METAL CHIP	10K 5% 1/10W				
R74	1-216-013-00	METAL CHIP	33 5% 1/10W				

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
		MISCELLANEOUS *****				***** HARDWARE LIST *****	
15	1-751-690-11	WIRE (FLAT TYPE) (21 CORE)		#1	7-682-547-09	SCREW +BVTT 3X6 (S)	
16	1-751-659-11	WIRE (FLAT TYPE) (22 CORE)		#2	7-685-870-01	SCREW +BVTT 3X5 (S)	
17	1-751-688-11	WIRE (FLAT TYPE) (13 CORE)		#3	7-685-647-79	SCREW +BVTP 3X10 TYPE2 N-S	
△155	8-848-144-11	DEVICE, OPTICAL KSS-240A		#4	7-685-531-14	SCREW +BTP 2.6X4 TYPE2 N-S	
156	1-575-001-11	WIRE, FLAT TYPE (12 CORE)		#5	7-621-770-XX	SCREW +PTT 2.6X8 (S)	
158	1-751-597-11	WIRE (FLAT TYPE) (22 CORE)		#6	7-685-533-19	SCREW +BTP 2.6X6 TYPE2 N-S	
M101	X-4917-523-3	MOTOR ASSY, DISK (SPINDLE)		#7	7-682-546-09	SCREW +PTT 3X5 (S)	
M102	X-4917-504-1	MOTOR ASSY (SLED)		#9	7-621-775-00	SCREW +B 2.6X3	
M103	A-4660-232-A	MOTOR (CDM) ASSY (LOADING)		#8	7-685-645-79	SCREW +BTP 3X6 TYPE2 N-S	
M104	A-4660-232-A	MOTOR (CDM) ASSY (UP/DOWN)		#10	7-685-131-19	SCREW +BTP 2.6X4 TYPE2 N-S	
M105	A-4660-232-A	MOTOR (CDM) ASSY (CLAMP)		#11	7-621-773-95	SCREW +BVTT 2.6X6 (S)	
S101	1-572-085-11	SWITCH LEAF (LIMIT)		#12	7-685-134-19	SCREW +BTP 2.6X8 TYPE2 N-S	
S102	1-466-819-11	ENCODER, ROTARY					

		ACCESSORIES & PACKING MATERIALS *****					
	1-467-258-11	REMOTE COMMANDER (C70:AEP, G, IT)					
	1-501-374-11	ANTENNA, LOOP (C70:AEP, G, IT)					
	1-501-594-11	ANTENNA (FM) (C70:AEP, G, IT)					
△	1-575-131-11	CORD, POWER (C70:AEP, G, IT)					
	1-751-469-11	CORD (WITH CONNECTOR) (C70:AEP, G, IT)					
	3-372-531-01	SCREW (C), TRANSPORT					
	3-757-494-11	MANUAL, INSTRUCTION (ENGLISH) (AEP)					
	3-757-494-41	MANUAL, INSTRUCTION (FRENCH, SPANISH, SWEDISH, PORTUGUESE, DUTCH) (AEP)					
	3-757-494-51	MANUAL, INSTRUCTION (GERMAN, ITALIAN) (AEP, G, IT)					
	3-707-584-21	COVER (MLY), BATTERY (COMMANDER) (C70:AEP, G, IT)					
*	4-960-930-01	INDIVIDUAL CARTON (C70:AEP, G, IT)					
*	4-960-933-01	CUSHION (H) (FRONT) (C70:AEP, G, IT)					
*	4-960-934-01	CUSHION (H) (REAR) (C70:AEP, G, IT)					

The components identified by mark
△ or dotted line with mark △ are
critical for safety.
Replace only with part number
specified.

Les composants identifiés par une
marque △ sont critiques pour la
sécurité.
Ne les remplacer que par une pièce
portant le numéro spécifié.